Installer Guide

PowerMax10

Fully supervised wireless alarm control system

Visonic®

For a secure way of life

English

PowerMax10-G2

Wireless Intrusion and Fire Alarm system

Visonic®

Installer Guide

TABLE OF CONTENTS

1. INTRODUCTION 3
2. SPECIFICATIONS 3
2.1 Functional 3
2.2 Wireless 3
2.3 Electrical 3
2.4 Communication 3
2.5 Physical Properties 4
3. INSTALLATION 4
3.1 Supplying Power to the Unit 4
3.1.1 Inserting Backup Battery 4
3.1.2 Connecting Power to Panel 4
3.1.3 Telephone Wiring 4
3.2 System Planning & Programming 6
3.3 Mounting the Unit 6
3.4 Extension Modules Installation 7
3.4.1 GSM Installation 7
3.4.2 PowerLink Installation 7
3.5 Closing the Control Panel 7
4. PROGRAMMING 8
4.1 General Guidance 8
4.2 Navigation 8
4.3 Permissions and User Codes 8
4.3.1 Setting a New Installer Code 8
4.3.2 Setting the Master Installer Code 9
4.3.3 Setting User Codes 10
4.3.4 Enabling User Permit for Installer Access 10
4.3.5 Configuring Permissions for System Reset after Alarm Event 10
4.3.6 Configuring a Duress Code 11
4.4 Zones / Devices 12
4.4.1 General Guidance 12
4.4.2 Adding a Wireless Device 12
4.4.2.1 Assigning a Location, Zone type and Chime Option 13
4.4.2.2 Configuring Device Parameters 14
4.4.2.3 Zone Types 14
4.4.2.4 Locations 15
4.4.3 Adding Wired Zones 16
4.4.4 Deleting a Device 17
4.4.5 Modifying a Device 18
4.5 Siren Configuration 19
4.5.1 Configuring the Length of Time the Bell is Allowed to Function 19
4.5.2 Enabling the Internal Siren 19
4.5.3 Configuring the Period of Strobe Light Activation 20
4.5.4 Enabling Siren Activation upon Telephone Line Failure 20
4.6 Event Reporting Configuration 21
4.6.1 General 21
4.6.2 Setup Report Communicators 21
4.6.2.1 Configuring PSTN / GSM Communicators 21
4.6.2.2 Configuring GPRS / BB Communicators 22
4.6.3 Configuring Event Reporting to Monitoring Station. 25
4.6.3.1 Configuring the Types of Events to be Reported 26
4.6.3.2 Configuring the Communicators Report Sequence 26
4.6.3.3 Configuring Account Numbers to be Reported to the Monitoring Station 27
4.6.3.4 Configuring the Monitoring Station's Telephone Numbers and IP Addresses 28
4.6.3.5 Configuring the Report Method (Protocol) to Monitoring Station 30
4.6.3.6 Configuring the Number of Retry Attempts 30
4.6.3.7 Configuring the Auto Test Report 31
4.6.3.8 Configuring the Event Types to be Reported to the Monitoring Station 33
4.6.4 Configuring Event Reporting to Users 34
4.7 Security System Configuration 37
4.7.1 Enable Cross Zoning 37
4.7.2 Configuring Swinger Stop 38
4.7.3 Enable Monitoring of Activity at Home 39
4.7.4 Configuring Alarm Cancel Period 39
4.7.5 Configuring Power Failure Threshold Period 40
4.7.6 Configuring Abort Time 40
4.7.7 Configuring a Confirmed Alarm 41
4.7.8 Enable Alarm upon Detection of Jammed or Missing Device 42
4.7.9 Configuring the Jamming Detection 42
4.7.10 Configuring Whether a Missing Device Causes the System to Become "NOT READY" 43
4.7.11 Configuring the Time Period by which a Device is considered Missing 44
4.8 Arming/Disarming Options And Exit/Entry Delay .. 44
4.8.1 Configuring Exit Modes 44
4.8.2 Configuring Entry Delays Duration 45
4.8.3 Configuring Exit Delay Duration 46
4.8.4 Enabling Quick Arm 46
4.8.5 Configuring Bypassing Zones 47
4.8.6 Configuring Panic Alarm Activation 47
4.8.7 Enabling Latchkey Arming 48
4.9 User Interface Customization 49
4.9.1 Enabling Trouble Beeps 49
4.9.2 Enabling Piezo Beeps 49
4.9.3 Enabling the Back Light 50
4.9.4 Configuring the Disarm Option 50
4.9.5 Configuring the Screen Saver Options 51
4.9.6 Enabling the Memory Prompt 52

4.9.7 Enabling Keyfob Low Battery Acknowledgement 52
4.10 DEFINE CUSTOM LOCATIONS 53
4.11 CONFIGURING OUTPUT PARAMETERS 54
4.11.1 Preliminary Guidance 54
4.11.2 Define PGM 54
4.12 Programming User Settings 58
Configuring Remote Programming Access Permissions 59
5 DIAGNOSTIC TEST 61
5.1 Testing Devices 62
5.1.1 Testing all Devices 62
5.1.2 Testing One Device 62
5.1.3 Displaying Signal Strength Indication of All Devices 63
5.1.4 Displaying Signal Strength Indication of RF Devices 63
5.1.5 GPRS Communication Test 64
5.1.6 LAN Connection Test 65
5.1.7 LAN Reset Option 66
6 CALLING UPLOAD/DOWNLOAD SERVER 67
7. MAINTENANCE 68
7.1 Handling System Troubles 68
7.2 Dismounting the Control Panel 69
7.3 Replacing the Backup Battery 69
7.4 Fuse Replacement 69
7.5 Replacing/Relocating Detectors 69
7.6 Restore Factory Defaults 69
7.7 Viewing Serial Number 70
8 READING THE EVENT LOG 70
8.1 Reading the Event Log 70
8.2 Erasing and Exiting the Event Log 71
APPENDIX A. Detector Deployment & Transmitter Assignments 71
A1. Detector Deployment Plan 71
A2. Keyfob Transmitter List 72
A3. Emergency Transmitter List 72
A4. Non-Alarm Transmitter List 72
APPENDIX B. Event Codes 73
B1. Contact ID Event Codes 73
B2. SIA Event Codes 73
B3. 4/2 Event Codes 73
B4. Understanding the Scancom Reporting Protocol Data Format 74
APPENDIX C. Glossary 74
APPENDIX D. DEFAULT AND PROGRAMMED ZONE DEFINITIONS 76

MESSAGE TO THE INSTALLER

The PowerMax10-G2 control panel is supplied with 3 instruction manuals:

■ **Installer Guide** (this manual - for your exclusive use)

■ **User's Guide** (for your use during installation only - Must be handed over to the master user after testing the system)

■ **Accessories Guide** (includes a full description of devices that are supported by the PowerMax10-G2 system)

Appendices A.1 and A.2 will help you prepare an installation plan. Please take time to fill out the forms - your job will become much easier and confusion will be prevented. Filling out the forms will also help you create a list of detectors and transmitters that must be obtained for the particular application. Compatible detectors and transmitters are listed in the Accessories Guide.

Remember - it is advisable to power up the control panel temporarily after unpacking and program it on the work bench, in accordance with the installation plan.

Although setting the correct time and date is one of the user tasks, we recommend that you set the time and date in the course of programming. Access to the "User Settings" for the installer is possible through the installer's menu or through the user menu (see User's Guide section 2).

After programming, proceed to install the system as detailed in the Installation Instructions, from paragraph 3.3 Mounting the Unit onward.

The installer should verify line seizure. Be aware of other phone line services such as DSL. If DSL service is present on the phone line, you must install a filter. It is suggested to use the DSL alarm filter model Z-A431PJ31X manufactured by Excelsus Technologies, or equivalent. This filter simply plugs into the RJ-31X jack and allows alarm reporting without breaking the internet connection.

1. INTRODUCTION

The PowerMax10-G2 is a user and installer-friendly, 29-zone fully-supervised wireless control system.
The system is designed to function in an appealing way to the user and also offers features that make installers' life easier than ever before:

EASY TO MAINTAIN

- Alarm memory and trouble data are displayed upon request.
- Diagnostic test provides visual and audible indication of the signal level of each detector.
- Remote control from distant telephones.
- Event log stores and displays information.
- Upload / download from distant computer via telephone line or cellular modem.

QUICK PROGRAMMING

- Simple programming logic, fully menu driven.
- Multiple-choice selection of options for each parameter.
- Unequivocal visual prompts.
- Installer access to the user menu.

2. SPECIFICATIONS

2.1 Functional

Zones Number: 28 wireless zones, 1 hardwired input.
Hardwired Zone Requirements: 2.2 kΩ E.O.L. resistance (max. resistance of wires 220 Ω).
Zone Types: Interior follower, interior, perimeter, perimeter follower, delay 1, delay 2, 24h silent, 24h audible, fire, non-alarm, emergency, gas, flood, temperature and home/delay.
User Codes: 8 codes, 4 digits each (9999 different combinations). Code 0000 is not allowed.
Control Facilities:
- Integral keypad
- PowerG / Code-Secure™ hand-held transmitters.
- Two way keypads.
- SMS commands via optional GSM/GPRS module.
- Remote control by telephone.

Note: *For SIA CP-01 compliance, when using KF-234 PG2 an external siren must also be used.*
Display: Single line, backlit 16-character LCD.
Arming Modes: AWAY, HOME, AWAY-INSTANT, HOME-INSTANT, LATCHKEY, FORCED, BYPASS.
Alarm inhibited during a single arming period (swinger stop) after: 1, 2, 3, alarm/tamper/fault, or not inhibited (programmable / selectable).
Note: *To comply with EN requirements, the swinger stop should be set to 3.*
Alarm Types: Silent alarm, siren alarm (future option) or sounder (internal) alarm, in accordance with zone attributes.
Siren Signals: Continuous (intrusion / 24 hours / panic); triple pulse - pause - triple pulse... (fire).
Siren (bell) Timeout: Programmable (4 min. by default).
Internal Sounder Output: At least 85 dBA at 10 ft (3 m).
Supervision: Programmable time frame for inactivity alert
Special Functions:
- Chime zones
- Diagnostic test and event log.
- Local and Remote Programming over Telephone, GSM /GPRS connections.
- Calling for help by using an emergency transmitter.
- Tracking inactivity of elderly, physically handicapped and infirm people.

Data Retrieval: Alarm memory, trouble, event log.
Real Time Clock (RTC): The control panel keeps and displays time and date. This feature is also used for the log file by providing the date and time of each event.
Compliance with U.S. Standards:
USA: (FCC) CFR 47part 15 and part 68, UL 1023, UL 985, UL 1635, UL 1637, SIA CP-01
Canada: RSS 210, ULC S545-02, ULC C1023,CSA C22.2#205

Compliance with European CE Standards:
The PowerMax10-G2 has been certified to EN 50082-1, EN301489-3,7, EN61000-4-6, EN60950, EN300220, EN50130-4, EN50130-5, EN50131-3, EN50131-6 tested by the Dutch testing and certification body Telefication B.V.

The PowerMax10-G2 is compatible with the RTTE requirements - Directive 1999/5/EC of the European Parliament and of the Council of 9 March 1999.

According to the European standard EN50131-1, the PowerMax10-G2 security grading is 2 – "low to medium risk" and environmental classification is II – "indoor general" and the power supply type is A.

GSM standards:
Europe: Complies with CE standards 3GPP TS 51.010-1, EN 301 511, EN301489-7
USA: CFR 47 Part 22 (GSM850) and Part 24 (GSM 1900). EMC standard: CFR 47 Part 15.

2.2 Wireless

Operating Frequencies (MHz): 315 (in USA & Canada), 433.92, 868.95 or other UHF channel per local requirement in the country of use.
Receiver Type: Super-heterodyne, fixed frequency
Receiver Range: 600 ft (180 m) in open space
Antenna Type: Spatial diversity
Coding: PowerG and/or CodeSecure™

2.3 Electrical

External AC/AC adapter:
- **Europe:** 230VAC 50Hz input, 9VAC 700mA output.
- **USA:** 120VAC 60Hz input, 9VAC 1000mA output.

Current Drain: Approx. 70 mA standby, 1600 mA peak at full load.
Minimum battery voltage: 4.8V
Note: *For CE compliance the battery backup period shall exceed 12 hours.*
Backup Battery Pack: 4.8V 1300 mAh, rechargeable NiMH battery pack, p/n GP130AAM4YMX, manufactured by GP or equivalent.
Note: *For compliance with UL standards the battery backup period shall exceed 24 hours.*
Backup Battery Pack: 4.8V 2200 mAh, rechargeable NiMH battery pack, p/n GP230AAHC4YMX, manufactured by GP.
Battery Test: Once every 10 seconds.

2.4 Communication

Built-in Modem: 300 baud, Bell 103 protocol
Data Transfer to Local Computer: Via RS232 serial port
Report Destinations: 2 Monitoring Stations, 4 private telephones.
Reporting Format Options: SIA, Pulse 4/2 1900/1400 Hz, Pulse 4/2 1800/2300 Hz, Contact ID, Scancom.
Pulse Rate: 10, 20, 33 and 40 pps - programmable
Message to Private Phones: Tone

Ring Detection: The unit does not support ring detection without DC voltage present on the telephone lines.

2.5 Physical Properties

Operating Temp. Range: 14°F to 120°F (-10°C to 49°C)
Storage Temp. Range: -4°F to 140°F (-20°C to 60°C)
Humidity: 85% relative humidity, @ 30°C (86°F)
Size: 193 x 178 x 50 mm (7-5/8 x 7 x 2 in.)
Weight: 658g (23 Oz) (with battery)
Color: White

3. INSTALLATION

Note: *This system must be checked by a qualified technician at least once every three (3) years.*

3.1 Supplying Power to the Unit

Connect power to the PowerMax10-G2 temporarily (see Figure 3.2). Alternatively, you may power up from the backup battery, as shown in Figure 3.1.
Disregard any "trouble" indications pertaining to lack of battery or lack of telephone line connection.

For Europe Safety Compliance:

a. The model shall be installed according to the local electrical code.
b. The circuit breaker shall be readily accessible.
c. The rating of the external circuit breaker shall be 16A or less.
d. The cables for the AC mains connection shall have an overall diameter of 13mm and 16mm conduit.

Please refer to Figure 3.2 "Power Cable Connection".

3.1.1 Inserting Backup Battery

Connect battery pack as shown in the next drawing.



1. Battery insertion
2. Battery connection

Figure 3.1 – Connecting Battery

3.1.2 Connecting Power to Panel

Connect the power cable and close the control panel as shown below. Electrical socket-outlet shall be installed near the equipment and shall be easily accessible.

WARNING! *DO NOT USE AN OUTLET CONTROLLED BY A WALL SWITCH.*

Note: *This equipment should be installed in accordance with Chapter 2 of the National Fire Alarm Code, ANSI/NFPA 72, (National Fire Protection Association).*



Connect the power adapter to the power connector.

Fig. 3.2 - Power Cable Connection

3.1.3 Telephone Wiring

PHONE WIRING

Connect the telephone cable to the SET connector and connect the telephone line cable to the LINE connector (through the desired wiring cable entry).



A. SET
B. LINE
C. Tel line wall jack

PHONE WIRING IN NORTH AMERICA



A. SET
B. LINE
C. RJ-31X cord
D. 8-position RJ-31X plug
E. Gray
F. Red
G. Green
H. Brown
I. RJ-31X jack
J. Line from street
K. House phones

This equipment is designed to be connected to the telephone network using RJ11 connector which complies with Part 68 rules and requirements adopted by ACTA and properly installed RJ31X connector. See drawing below for details.

In the case that RJ31X is not available (consult your telephone company or a qualified installer), the telephone line should be connected to the PowerMax10-G2 unit first and then all other home equipment should be connected to PowerMax10-G2 "Phone" outlet.

Customer Premises Equipment And Wiring



A. Network Service Provider's Facilities
B. Telephone Line
C. Network Demarcation Point
D. RJ-31X Jack
E. Telephone
F. Alarm Dialing Equipment
G. Answering System
H. Unused RJ-11 Jack
I. Fax Machine
J. Computer

Note: *The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company.*

Connection to telephone company provided coin service is prohibited. Connection to party lines service is subject to state tariffs.

3.2 System Planning & Programming

It pays to plan ahead - use the tables in appendices A and B at the end of this guide to register the intended location of each detector, the holder and assignment of each transmitter.

Gather up all transmitters and detectors used in the system and mark each one in accordance with your deployment plan.

Program the system now, before mounting, as instructed in the programming section.

3.3 Mounting the Unit

Required tool: Philips screwdriver #2.

PowerMax10-G2 mounting process is shown in Figure 3.3 - 3.4.



A. Mounting surface
B. Back unit

To Mount the Unit:

1. Release the screws
2. Remove the front cover
3. Mark 4 drilling points on the mounting surface
4. Drill 4 holes and insert wall anchors
5. Fasten the back unit with 4 screws

Figure 3.3 – Back Unit Mounting

WARNING! *When plugging SIREN & ZONE terminals back into place, be sure to align them carefully with the pins on the PCB. Misaligned or reverse insertion of terminals may damage internal PowerMax10-G2 circuits!*

3.4 Extension Modules Installation

3.4.1 GSM Installation

The internal GSM 350 module enables the PowerMax10-G2 system to operate over a GSM/GPRS cellular network (for further details, see the GSM 350 PG2 Installation Instructions).

The GSM modem auto detection feature enables automatic enrollment of the GSM modem into the PowerMax10-G2 control panel memory. GSM modem auto detection is activated in one of two ways: after tamper restore and after reset (power-up or after exiting the installer menu). This causes the PowerMax10-G2 to automatically scan GSM COM ports for the presence of the GSM modem.

In the event that the GSM modem auto detection fails and the modem was previously enrolled in the PowerMax10-G2 control panel, the message "Cel Rmvd Cnfrm" will be displayed. This message will disappear from the display only after the user presses the OK button. The modem is then considered as not enrolled and no GSM trouble message will be displayed.

Note: *A message is displayed only when the PowerMax10-G2 alarm system is disarmed*.

3.4.2 PowerLink Installation

The PowerLink module enables viewing the PowerMax10-G2 system over the internet (for further details, see the PLINK PRO Installation Instructions).

The Broadband Module modem auto detection feature enables automatic enrollment of the Broadband Module modem into the PowerMax10-G2 control panel memory. Broadband Module modem auto detection is activated in one of two ways: after tamper restore and after reset (power-up or after exiting the installer menu). This causes the PowerMax10-G2 to automatically scan the Broadband Module COM ports for the presence of the Broadband Module modem.

In the event that the Broadband Module modem auto detection fails and the modem was previously enrolled in the PowerMax10-G2 control panel, the message "BBA Remvd Cnfrm" will be displayed. This message will disappear from the display only after the user presses the OK button. The modem is then considered as not enrolled and no Broadband Module trouble message will be displayed.

Notes:

A message is displayed only when the PowerMax10-G2 alarm system is disarmed.

In the event of a power failure the Broadband Module will not operate. Power (AC or battery) must be disconnected from the circuit before connecting / disconnecting the Broadband Module.

3.5 Closing the Control Panel

Control panel final closure is shown below.



To Close the Control Panel:

1. Close the front cover

2. Fasten the screws

Figure 3.4 - Final Closure

4. PROGRAMMING

4.1 General Guidance

We recommend programming the PowerMax10-G2 on the work bench before actual installation. Operating power may be obtained from the backup battery or from the AC power supply.

4.2 Navigation

This mode allows you to customize the control panel and adapt its characteristics and behavior to the requirements of the particular user. To review the options within the control panel menus, repeatedly press the ▶▶ or ◀┘ button, until the desired option is displayed, then press the OK button.

You will mainly use 5 control pushbuttons during the entire programming process:

▶▶	- to move one step forward in a menu.
◀┘	- to move one step backward in a menu.
OK	- to enter the relevant menu or confirm data.
↑	- to move one level up in a menu.
⌂	- to return to the "OK TO EXIT" state.

The sounds you will hear while programming are:

♩	**- Single beep, heard whenever a key is pressed.**
♩♩	**- Double beep, indicates automatic return to the normal operating mode (by timeout).**
☺	- **Happy Melody** (- - - ——), indicates successful completion of an operation.
☹	- **Sad Melody** (———), indicates a wrong move or rejection.

If you enter an invalid installer code 5 times, the keypad will be automatically disabled for 90 seconds and the message WRONG PASSWORD will be displayed.

4.3 Permissions and User Codes

The PowerMax10-G2 system includes four code levels, as follows:

- **Installer Code:** By using the installer code, the menu enables changing the installer code.
- **Master Installer Code:** By using the master installer code, the menu enables changing both master installer code and installer code.
- **User Code:** See PowerMax10-G2 User Guide
- **Master User Code:** See PowerMax10-G2 User Guide

Not every system includes a MASTER INSTALLER code. In a system with an INSTALLER code only, the installer can use all the functions in the system.

The following actions can be done only by using the master installer code:

- Changing master installer code.
- Resetting the PowerMax10-G2 parameters to the default parameters,
- Defining specific communication parameters.

You are expected to use this code only once for gaining initial access, and replace it with a secret code known only to yourself.

4.3.1 Setting a New Installer Code

To set an installer code, perform the actions that are presented below. When you are instructed to enter code, enter a 4-digit code.

A. To Set a New Installer Code

1. Make sure the system is disarmed and then press the ▶▶ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.

The screen will now prompt you to enter your installer code.*

* The default Installer Code is 9999.

3. Enter your Installer Code.

4. When the PowerMax10-G2 display reads [NEW INSTL CODE], press [OK].

The PowerMax10-G2 display will read [NEW MASTER CODE].

Note: *The menu displays within the dashed box appear only if the control panel includes the Master Installer Code.*

5. Press the [▸▸] button.

6. When the PowerMax10-G2 display reads [NEW INST. CODE], press [OK].

7. Enter the new 4-digit Installer Code (8888 or 9999) at the position of the blinking cursor and then press [OK].

The PowerMax10-G2 display *reads [NEW INST. CODE] and* a *"Happy Tune" ♫☺ sounds to confirm the new Installer Code.*

If your system uses MASTER CODE, you should proceed to setting the MASTER INSTALLER code in section 4.3.2 by pressing the [▸▸] button, or press the [🔒] button to take you to "<OK> TO EXIT".



Note: Installer *Code should never be programmed as "0000". Doing so will lock the user out of the installer menu!*

4.3.2 Setting the Master Installer Code

For PowerMax10-G2 with MASTER INSTALLER code, set a new INSTALLER code as described in section 4.3.1 "Setting a New Installer Code" and set the MASTER INSTALLER code as described in this section.

Note: *For Control Panel that has installer code & master installer code, the following functions are available only if the MASTER INSTALLER code is entered:*

- PSTN/GSM RCVR1
- RCVR 1 ACCOUNT#
- PSTN/GSM RCVR2
- RCVR 2 ACCOUNT#
- PSTN RPRT FORMAT
- 4/2 PLS RATE
- REPORT EVENTS
- RPRT CNFRM ALRM
- SEND 2WV CODE
- VOICE Monitoring Station.
- RINGBACK TIME
- PSTN RPRT RETRY
- GSM RPRT RETRY
- MAST. DL CODE

By using the master installer code, the menu enables changing both master installer code and installer code.
By using the installer code, the menu enables changing the installer code only.

B. To Set a New Master Installer Code

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].

The screen will now prompt you to enter your installer code.*

3. Enter your Installer Code.

4. When the PowerMax10-G2 display reads [NEW INSTL CODE], press [OK].

The PowerMax10-G2 display will read [NEW MASTER CODE].

5. Press [OK].

6. Enter the new 4-digit Installer Code at the position of the blinking cursor and then press [OK].



The PowerMax10-G2 display *reads [NEW MASTER CODE] and* a *"Happy Tune"* ♫☺ *sounds to confirm the new MASTER INSTALLER code*.

You can now press the ▸▸ *button to set the INSTALLER code* or *press the* 🔒 *button to take you to "<OK> TO EXIT"*.

♫☺

Note: Master Installer *Code should never be programmed as "0000". Doing so will lock the user out of the installer menu!*

4.3.3 Setting User Codes

For detailed instructions on setting user codes, refer to the PowerMax10-G2 user guide "Menus and Functions".

4.3.4 Enabling User Permit for Installer Access

User Permission enables you to determine whether access to the INSTALLER MODE requires user permission. Access to the installer menu, in PowerMax10-G2 that has "User Permission" enabled (for example, in UK) is via the last menu in the user menu. This option can be changed, if necessary. Here you determine whether the access to the INSTALLER MODE requires user permission. If you select ENABLE, the installer mode will be accessible only through the user menu after entering the user code.

Options: **Enable** (default in UK), **Disable** (default).

Note: *To comply with EN requirements, "Enable" must be selected.*

To Enable User Permit for Installer Access



1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press i OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the ▸▸ or ◂ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press i OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▸▸ or ◂ button repeatedly until the display will read [36:USER PERMIT].
7. Press i OK and select between "Disable" (default) and "Enable" and then press i OK to confirm.

♫☺

The PowerMax10-G2 display reverts to "36:USER PERMIT" and a *"Happy Tune"* ♫☺ *sounds*.

You can now press the ▸▸ *or* ◂ *button to program any other menu in "DEFINE PANEL"* or *press the* 🔒 *button to take you to "<OK> TO EXIT"*.

4.3.5 Configuring Permissions for System Reset after Alarm Event

(Not applicable in the USA)

Here you determine whether the system can be rearmed (after an event) by the user or only by the installer.

Options: **user reset** (default), **engineer reset**, or **anti code reset**.

If Engineer Reset is selected, the system can be rearmed only by the installer; by entering and exiting the installer menu, by entering and exiting the event log (see section 8), or by remote telephone. To perform Engineer Reset via the telephone, establish communication with the PowerMax10-G2 (see user guide, Chapter 5) and continue as follows:

a. ☞ [*], [installer code], [#]

b. Wait for 2 beeps

c. ☞ [*], [1], [#]

d. ☞ [*], [99], [#]

Visonic uses Technistore anti code reset. Installers should check with their Monitoring Station for a code version (seed code) which needs to be entered.

To Configure Permissions for System Reset after an Alarm Event

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.[2]
4. Press the ▸▸ or ◂ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▸▸ or ◂ button repeatedly until the display will read [25:RESET OPTIONS].
7. Press OK and make the selection and then press OK to confirm.



The PowerMax10-G2 display reverts to "25:RESET OPTION" and a "Happy Tune" ♫☺ sounds.

You can now press the ▸▸ or ◂ button to program any other menu in "DEFINE PANEL" or press the 🔒 button to take you to "<OK> TO EXIT".

4.3.6 Configuring a Duress Code

A duress alarm (ambush) message can be sent to the Monitoring Station if the user is forced to disarm the system under violence or menace. To initiate a duress message, the user must disarm the system with the duress code (2580 by default). Here you can change the code digits or enter "0000" to disable the duress feature. **The system does not allow the user to program the duress code saved in this memory location as an existing user code.**

Note: *Duress Code is not applicable in the UK.*

To Configure a Duress Code

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the ▸▸ or ◂ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▸▸ or ◂ button repeatedly until the display will read [23:DURESS].
7. Press OK, change the code or enter 0000 to disable the duress function and then press OK to confirm.



The PowerMax10-G2 display reverts to "23:DURESS" and a "Happy Tune" ♫☺ sounds.

You can now press the [▸▸] or [↩] button to program any other menu in "DEFINE PANEL" or press the [🔒] button to take you to "<OK> TO EXIT".

♫☺

4.4 Zones / Devices

4.4.1 General Guidance

The ZONES / DEVICES mode enables the following functions:
- Defining default parameters common for each devices family.
- Adding new devices (enrolling) and defining their zones name, zone type and chime zone.
- Deleting devices.
- Modifying devices parameters.
- Reviewing devices parameters.

Enrolling can be performed for Keyfobs (multi-button), wireless detectors, wireless sirens and repeaters.

The control panel enables entering a device identification (ID) instead of enrolling an actual device. This enables pre-enrolling off site.

Upon boot up, the control panel checks if there are pre-enrolled devices that have not yet been registered (ID of the devices are entered but the devices have not communicated with the control panel). In this case, the control panel will display "SYNC WITH DEV" on the LCD and the trouble LED will be on until all the devices have registered or the pre-enrolled devices that have not registered will be deleted from the enrollment menu.

Refer to sections 4.4.3 and 4.4.4 for detailed instructions on Enrolling/Deleting a device.

Notes
- Keyfob enrolling can be performed also by the user (via USER SETTINGS menu).
- Wired magnetic contact or any other contact can be enrolled in zones 29 & 30.
- Wireless detectors can be enrolled in zones 01-28.

Before beginning, gather all the devices that you intend to enroll and make sure they all have batteries installed.

Your control panel must recognize the unique identification code (ID) of each such detector in order to supervise them, receive their signals and respond accordingly.

- *Before enrolling, the lens at the front of PIR and dual-technology sensors should be masked to prevent inadvertent transmission.*
- *Make sure that magnetic contact transmitters are together with their magnets, to prevent them from sending out alarm transmissions.*

4.4.2 Adding a Wireless Device

This section describes how to add a new device to the PowerMax10-G2 control panel.

Note: *It is much easier to enroll the device while holding the device in your hand, close to the control panel.*

A. To Add a Device

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

☞[▸▸]

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [i OK].

☞[i OK]

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

☞**CODE**

The PowerMax10-G2 display will read [NEW INSTL CODE].

4. Press the [▸▸] button and select the [ZONES/DEVICES] option.

☞[▸▸]

5. When the PowerMax10-G2 display reads [ZONES/DEVICES] press [i OK]

☞[i OK]

The PowerMax10-G2 display will read [ADD NEW DEVICES].



6. Press [i OK]. You are now instructed to enroll the device.

☞[i OK]

7. Enter the 7-digit number printed on the back side of the device and press [i OK].*

↻

or



Perform the enrollment sequence for the specific device**:**

☞[i OK]

For most devices: Remove the device bracket or cover and press the device's

Enroll button continuously until the red & green LEDs turn ON and then release. The PowerMax10-G2 will indicate the result on its LCD display.

For Keyfobs: Press the '*' button until the red LED blinks rapidly and then release (the LED will continue blinking) then press the same button again. The LED lights green and the PowerMax10-G2 will indicate the result on its LCD display.

The PowerMax10-G2 display reads [DEVICE ENROLLED] (or [ID accepted] if the device was enrolled manually by entering the ID number), a "Happy Tune" ♫☺ sounds and the PowerMax10-G2 display will then change to [K01:Keyfob / Z01:Motion Sens / S01:Siren depending on the type of enrolled device].

However, if the device was previously enrolled in the system, the PowerMax10-G2 display reads [ALREADY ENROLLED].

Repeat the above procedure for each device to be enrolled in the PowerMax10-G2 system.

Continue to section 4.4.2.1 Assigning a Location, Zone Type and Chime Option.

When exiting "ZONES / DEVICES" menu the PowerMax10-G2 system displays the number of devices that need to be updated, as follows: DEV UPDATING NNN.

** If you enter the 7-digit number, you must physically install the device to complete the procedure. If the device is not installed, the system will display the device as "NOT NET" (device is pre-enrolled – not networked).*

You can now press the [▸▸] button to enroll the next device of the same type or press the [i OK] button to move to the "LOCATION" menu (see section 4.4.2.1) or press the [⌂] button to take you to "<OK> TO EXIT".



4.4.2.1 Assigning a Location, Zone type and Chime Option

B. To Assign a Location, Zone Type and Chime Option

The PowerMax10-G2 system behavior is defined according to one of 15 zone types assigned to each of the system's 30 (wireless & wired) zones.

Note: *This step is applicable to detectors only.*

Continue below from the previous section.

1. Press [i OK]. The PowerMax10-G2 display will read [Z01: LOCATION].

2. When the PowerMax10-G2 display reads [LOCATION], press [i OK].

The PowerMax10-G2 display will read [Front door].

3. Press the [▸▸] or [↰] button repeatedly to select a location, or, enter the location number, for example, "Master Bdrm".

4. Press [i OK] to confirm. The PowerMax10-G2 display will read [Z01:ZONE TYPE].

5. When the PowerMax10-G2 display reads [Z01: ZONE TYPE], press [i OK].

The PowerMax10-G2 display will read [12.Non-Alarm].

6. Press the [▸▸] or [↰] button repeatedly to select a zone type, or, enter the zone type number, for example, pressing 03 selects "3. Home Delay".
To understand the behavior of each zone, see section 4.4.2.3 Zone Types.

7. Press [i OK] to confirm. The PowerMax10-G2 display will read [SET CHIME].

8. Press [i OK] to change chime settings or press the [▸▸] button to skip. After pressing [i OK], the PowerMax10-G2 display will read [chime OFF ■].

9. Press the [▸▸] and [↰] buttons to select between "CHIME OFF" and "melody-chime".



In "melody chime" mode when a chime zone is triggered, chime melody is heard



10. Press OK to confirm.
The PowerMax10-G2 display will read [DEV SETTINGS].

11. Press the ▸▸ button.
The PowerMax10-G2 display will read [NEXT device]*.

12. Press the ▸▸ button.
The PowerMax10-G2 display will read [MODIFY SAME Dev.]*.

13. Press the ▸▸ button.
The PowerMax10-G2 display will read [EXIT Enrollment]*.

** When the PowerMax10-G2 will read "NEXT device" you can click the OK button to enroll the next device. When the PowerMax10-G2 will read "MODIFY SAME Dev" you can click the OK button to modify the same device. When the PowerMax10-G2 will read "EXIT Enrollment" you can click the OK button to revert to "ADD NEW DEVICES".*

4.4.2.2 Configuring Device Parameters

Refer to the PowerMax10-G2 Accessories Guide for detailed instructions on how to modify specific device settings for each device

4.4.2.3 Zone Types

Upon enrollment of a new detector (marked "Zxx") you must select the proper zone type. The zone type determines how the system handles alarms and other signals sent from the device.
A list of factory defaults is printed in Appendix D. You may fill out the blank columns even before you start and proceed to program according to your own list.
Zone types are fully explained below:

Delay Zones:
A delay zone has exit and entry delays set by you in the course of programming the system. Warning beeps will sound throughout these delays, unless you choose to mute them.

- **Exit Delay** - The exit delay begins once the user arms the system. It allows him to leave via interior zones and a doorway before arming actually takes effect. When the exit delay starts, the buzzer beeps slowly and maintains a slow beeping rate until the last 10 seconds, during which it beeps rapidly. The PowerMax10-G2 has two types of delay zones, for which different delay times may be set.
- **Entry Delay** - The entry delay begins once the user enters the protected area via a specific doorway (his entry is sensed by a delay zone detector). To avoid an alarm, he must reach the keypad via interior zones (which become "follower zones" during the entry delay) and disarm the system before the delay expires. When the entry delay starts, the buzzer beeps slowly until the last 10 seconds, during which it beeps rapidly.

Remember!
A delay zone is also a perimeter zone by definition.

Emergency Zones:
You can provide incapacitated, sick or elderly people with a miniature single-button transmitter to be carried on the neck like a pendant or to be worn on the wrist like a watch. In distress situations, they can press the button on their transmitter, causing the PowerMax10-G2 to send an **emergency call** to the Monitoring Station or to private telephones designated by the installer.

To make this possible, define the required number of zones as emergency zones and enroll a portable transmitter to each one of these zones. When completed, ask the master user to distribute these transmitters to their potential users.

Fire Zones:

A fire zone uses smoke detectors and is permanently active (a fire alarm is triggered regardless of whether the system is armed or disarmed). Upon detection of smoke, a **pulsating siren** sounds immediately and the event is reported via the telephone line.

Flood Zone:

A flood zone is permanently active (a flood alarm is triggered regardless of whether the system is armed or disarmed). Upon detection of flood leak, the event is reported via the telephone line.

Gas Zone:
A gas zone is permanently active (a gas alarm is triggered regardless of whether the system is armed or disarmed). Upon detection of gas leak, the event is reported via the telephone line.

Interior Zone:

Interior zones are zones within the protected premises that have nothing to do with perimeter protection. Their most important feature is that they allow free movement within the protected area without initiating an alarm, provided that the system is armed in the "HOME" mode. People can therefore stay at home and move about freely, as long as they do not disturb a PERIMETER zone.
Once the system is armed in the AWAY mode (all zones are protected), interior zones will initiate an alarm if violated.

Interior Follower Zones:
"Interior Follower" zone is a zone that is located between entry/exit zone and the alarm system control panel. This zone is temporarily ignored by the alarm system during entry/exit delay periods, to enable you to walk (without causing an alarm) in front of a motion detector that is associated with the Interior Follower zone, after you enter through an entry zone on the way to the control panel, or when leaving the protected premises after system arming.

Home/Delay Zones:
A zone type which functions as a delay zone when the system is armed HOME and as a perimeter-follower zone when the system is armed AWAY.

Non-Alarm Zones:
A non-alarm zone does not directly participate in the alarm system. It can be used for chime or for optional KEY ON-OFF feature (when enabled).
You can define the desired number of non-alarm zones and enroll a portable transmitter or a wireless device (detector) to this type of zone.

Perimeter Zones:
Perimeter zones rely on detectors designed to protect doors, windows and walls. An immediate alarm is initiated when such a zone is violated by opening the door/window or by trying to break the wall.

Perimeter Follower Zones:
A non-entry/exit zone, typically a perimeter zone located on an entry/exit path, that is treated as an entry/exit zone during an entry/exit time.

Temperature Zone:
A temperature zone uses a wireless temperature detector to detect both indoor and outdoor temperatures and is permanently active. The detector monitors room temperature using an internal sensor. For outdoor or refrigerator installations, a waterproof temperature probe (optional) is used. There are a total of four fixed temperature points and the user can enable one or more temperature points.
Upon detection of change in temperature a digital message is transmitted and the event is reported.

24-Hour Zones:

24 hour zones are mainly used for PANIC buttons, perimeter detectors and anti-tamper protection. They therefore trigger an alarm in both armed and disarmed states.

- **24 Hour Zone - Silent.** - Upon detection, this zone initiates a silent alarm, meaning that the sirens do not function. Instead the PowerMax10-G2 dials telephone numbers and reports the event to Monitoring Stations and/or to private telephones, as programmed.
- **24 Hour Zone - Audible.** - Upon detection, this zone initiates a siren alarm. The PowerMax10-G2 also dials telephone numbers and reports the event to Monitoring Stations and/or to private telephones, as programmed.

Key Zones (Optional):
Key zones are zones that can be used for arming and disarming the system by MCT-100 and MCT-102 PowerG transmitters that are enrolled to a zone. In addition, the alarm system may be armed / disarmed by a keyswitch when connected to wired zones 29 and 30.
Defining a zone as a KEY ZONE includes the following actions:
a. The zone should be defined as non-alarm type zone.
b. "Z-KEY ENABLE" should be selected for such a zone.
c. According to the zone number, **"z. 21-28 enable", "z.29-30 enable",** or **"z. 21-30 enable"** should be selected in the DEFINE PANEL menu.

4.4.2.4 Locations

You can select or assign a named location to a device (e.g. Garage, Front Door etc.). 31 locations can be selected, 26 fixed names and 5 custom names (defined by the installer).
Note: *Custom Locations can be defined via the DEFINE CUSTOM menu, and these custom names will also appear on your location list in addition to the default names.*
Note: *To facilitate assigning a location name to a device, a shortcut procedure may be used by entering the location number which takes you directly to the location name*.

Selectable Locations:

Attic
Back door
Basement
Bathroom
Bedroom
Child room
Closet (UK: Conservatory)
Den (UK: Playroom)
Dining room
Downstairs
Emergency
Fire
Front door
Garage
Garage door
Guest room
Hall
Kitchen

Laundry room
Living room
Master bath
Master bdrm
Office (UK: Study)
Upstairs
Utility room
Yard (UK: Garden)
Custom 1
Custom 2
Custom 3
Custom 4
Custom 5

4.4.3 Adding Wired Zones

Required tools: Cutter and slotted screwdriver - 3 mm blade.

PowerMax10-G2 wiring is shown in Figure 4.1.

CABLES ROUTING GUIDE



A. Cables entry options
B. Back unit
C. Cable clips

To Route the Cable:

1. Remove the left or right side cables entry knockout(s) and enter the required cable(s)
2. Remove and use as cable clamp(s)

ZONE WIRING



A. ZONE
B. TAMPER
C. ALARM

Note: *Do not use mains cable other than that supplied by the manufacturer (3 m long).*

Figure 4.1 - Wiring

4.4.4 Deleting a Device

C. To Delete a Device

1. Repeat steps 1 to 5 in section 4.4.3 "Adding a Device".

2. When the PowerMax10-G2 display reads [ADD NEW DEVICES] press the [▸▸] button.

The PowerMax10-G2 display will read [DELETE DEVICES].

3. Press [i OK].

The PowerMax10-G2 display will read [CONTACT SENSORS].

4. Press the [▸▸] or [↰] button repeatedly to select the type of device to be deleted. Select between "CONTACT SENSORS", "MOTION SENSORS", "SMOKE SENSORS", "WIRED SENSORS", "KEYFOBS", "SIRENS" and "REPEATERS" for example, "MOTION SENSORS".

5. Press the [i OK] button.

The PowerMax10-G2 display will read [Z01:Motion Sens].

6. Press the [▸▸] or [↰] button repeatedly to select the motion sensor to be deleted, for example, "Z03:Motion Sens".

7. Press the [i OK] button.

The PowerMax10-G2 display will read [<OFF> to delete].

8. Press the [⏎] button.

The PowerMax10-G2 display will revert to [MOTION SENSORS].

The device is deleted from the PowerMax10-G2 system.

When exiting "ZONES / DEVICES" menu the PowerMax10-G2 system displays the number of devices that need to be updated, as follows: DEV UPDATING NNN.



You can now press the [OK] button to delete the device of the same type, or press the [▸▸] button to delete a different device, or press the [⌂] button to take you to "<OK> TO EXIT".

4.4.5 Modifying a Device

D. To Modify a Device

Note: *This procedure is applicable to detectors only.*

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Press the [▸▸] button and select the [ZONES/DEVICES] option.

5. When the PowerMax10-G2 display reads [ZONES/DEVICES] press [OK]

The PowerMax10-G2 display will read [ADD NEW DEVICES].

6. When the PowerMax10-G2 display reads [ADD NEW DEVICES], press the [▸▸] or [↰] button repeatedly until the display will read [MODIFY DEVICES].

7. Press [OK].

The PowerMax10-G2 display will read [CONTACT SENSORS].

8. Press the [▸▸] or [↰] button repeatedly to select the desired sensor to be modified. Select between "CONTACT SENSORS", "MOTION SENSORS", "SMOKE SENSORS" and "WIRED SENSORS", for example, "MOTION SENSORS".*

9. When the PowerMax10-G2 display reads [Z01:Motion Sens] press [OK].

The PowerMax10-G2 display will read [LOCATION].

10. Press [OK]. The PowerMax10-G2 display will read [Z01: LOCATION].

11. When the PowerMax10-G2 display reads [LOCATION], press [OK].

The PowerMax10-G2 display will read [Front door].

12. Press the [▸▸] or [↰] button repeatedly to select a location, or, enter the location number, for example, "Master Bdrm".

13. Press [OK] to confirm. The PowerMax10-G2 display will read [Z01:ZONE TYPE].

14. When the PowerMax10-G2 display reads [Z01: ZONE TYPE], press [OK].

The PowerMax10-G2 display will read [12.Non-Alarm].

15. Press the [▸▸] or [↰] button repeatedly to select a zone type, or, enter the zone type number, for example, pressing 03 selects "3. Home Delay".
To understand the behavior of each zone, see section 4.4.2.3 Zone Types.

16. Press [OK] to confirm. The PowerMax10-G2 display will read [SET CHIME].

17. Press [OK] to change chime settings or press the [▸▸] button to skip.



After pressing [OK], the PowerMax10-G2 display will read [chime OFF ■].



18. Press the [▸▸] and [↰] buttons to select between "CHIME OFF" and "melody-chime".

In "melody chime" mode when a chime zone is triggered, chime melody is heard

19. Press [OK] to confirm. The PowerMax10-G2 display will read [DEV SETTINGS].

You can now press the [▸▸] button to modify the next device of the same type, or press the [OK] button to configure the parameters of the device (see the Accessories Guide for instructions), or press the [🔒] button to take you to "<OK> TO EXIT".

4.5 Siren Configuration

4.5.1 Configuring the Length of Time the Bell is Allowed to Function

Here you select the length of time the bell (or siren) is allowed to function upon alarm. The bell time starts upon activation of the siren. Once the bell time expires, the siren is automatically shut down.

Available options are: **1**, **3**, **4** (default), **8**, **10**, **15** and **20** minutes.

Note: *To comply with EN requirements, the Bell Time should be set to 15 min. max.*

To Configure the Length of Time the Bell is Allowed to Function

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Press the [▸▸] or [↰] button repeatedly and select the [DEFINE PANEL] option.

5. When the PowerMax10-G2 display reads [DEFINE PANEL], press [OK]

The PowerMax10-G2 display will read [01:ENTRY DELAY 1].

6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the [▸▸] or [↰] button repeatedly until the display will read [04:BELL TIME].

7. Press [OK] and make the selection and then press [OK] to confirm.

The PowerMax10-G2 display will revert to [04:BELL TIME].



You can now press the [▸▸] or [↰] button to program any other menu in "DEFINE PANEL" or press the [🔒] button to take you to "<OK> TO EXIT".

4.5.2 Enabling the Internal Siren

Here you determine whether the internal siren will sound or remain silent upon alarm (according to the user preference). Options: **piezo siren on** (default), **piezo siren off**.

To Enable the Internal Siren

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Press the ▶▶ or ◀ button repeatedly and select the [DEFINE PANEL] option.

5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK

   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].

6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▶▶ or ◀ button repeatedly until the display will read [24:PIEZO SIREN].

7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [24:PIEZO SIREN].



You can now press the ▶▶ or ◀ button to program any other menu in "DEFINE PANEL" or press the ⌂ button to take you to "<OK> TO EXIT".

4.5.3 Configuring the Period of Strobe Light Activation

Here you can define the period of strobe light activation when the siren is in alarm state. Options: **5 minutes, 10 minutes, 20 minutes** (default)**, 40 minutes and 60 minutes**.

To Configure the Period of Strobe Light Activation

1. Make sure the system is disarmed and then press the ▶▶ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.

   The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Press the ▶▶ or ◀ button repeatedly and select the [DEFINE PANEL] option.

5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK

   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].

6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▶▶ or ◀ button repeatedly until the display will read [40:STROBE TIME].

7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [40:STROBE TIME].



You can now press the ▶▶ or ◀ button to program any other menu in "DEFINE PANEL" or press the ⌂ button to take you to "<OK> TO EXIT".

4.5.4 Enabling Siren Activation upon Telephone Line Failure

Here you determine whether the siren will be activated or not when the telephone line fails during system armed state. Available options are: **enable on fail**, **disable on fail** (default).

To Enable Siren Activation upon Telephone Line Failure

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the ▸▸ or ◂ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▸▸ or ◂ button repeatedly until the display will read [27:SIREN ON LINE].
7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [27:SIREN ON LINE].

You can now press the ▸▸ or ◂ button to program any other menu in "DEFINE PANEL" or press the ⌂ button to take you to "<OK> TO EXIT".



4.6 Event Reporting Configuration

4.6.1 General

The PowerMax10-G2 system uses an IP platform that supports GSM and GPRS cellular communication and broadband to forward all events received at the control panel to the monitoring station.

4.6.2 Setup Report Communicators

4.6.2.1 Configuring PSTN / GSM Communicators

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the ☞▸▸ or ◂ button repeatedly until the PowerMax10-G2 display reads [DEFINE COMM.] option.
5. When the PowerMax10-G2 display reads [DEFINE COMM.], press OK.
   The PowerMax10-G2 display will read [1:PSTN/GSM]
6. When the PowerMax10-G2 display reads [1:PSTN/GSM] press the OK button.
   The PowerMax10-G2 display will read [AREA CODE].
7. Enter the system tel. area code (up to 4 digits).



8. Press [OK] to confirm.

The PowerMax10-G2 display will revert to [AREA CODE].

9. Press the [▸▸] button.

The PowerMax10-G2 display will read [LINE PREFIX].

10. Enter the number that is used as a prefix to access an outside telephone line (if exists).

11. Press [OK] to confirm.

The PowerMax10-G2 display will revert to [LINE PREFIX].

12. Press the [▸▸] button.

The PowerMax10-G2 display will read [DIAL METHOD]. Here you determine the dialing method used by the automatic dialer built into the PowerMax10-G2 control panel.

13. When the PowerMax10-G2 display reads [DIAL METHOD], press [OK].

The PowerMax10-G2 display will read [Pulse ■].

14. Press the [▸▸] or [◂] button to select between "Pulse" and "tone (dtmf)" for example, "tone (dtmf)"

15. Press [OK] to confirm the selection.

The PowerMax10-G2 display will revert to [DIAL METHOD].

16. Press the [▸▸] button.

The PowerMax10-G2 display will read [GSM KEEP ALIVE]. Here you prevent the GSM Service provider from disconnecting the GSM line if the user has not initiated any outgoing telephone calls during the last 28 days.

17. When the PowerMax10-G2 display reads [GSM KEEP ALIVE], press [OK].

The PowerMax10-G2 display will read [disable ■].

18. Press the [▸▸] or [◂] button to select between "disable" and "every 28 days", for example, "every 28 days".

19. Press [OK] to confirm the selection.

The PowerMax10-G2 display will revert to [GSM KEEP ALIVE].



You can now press the [▸▸] button to revert to the "AREA CODE" menu, or *press the [🔒] button to take you to "<OK> TO EXIT".*

4.6.2.2 Configuring GPRS / BB Communicators

The GSM/GPRS module is capable of communicating with the Monitoring station receiver by GPRS, GSM Voice and SMS Channels. Each of the channels can be separately enabled or disabled in order to allow or prohibit the module from using it for the event reporting. If all channels are enabled, the GSM/GPRS module will always try GPRS first. If fails, it will try GSM voice. If fails, it will try any other possible method (PSTN Broadband) and only then it will try SMS. This is due to the fact that SMS the most unreliable option of communication. Disabling any of the GSM Module channels will cause the module to use a different sequence than the one described above.

20. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

21. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].

The screen will now prompt you to enter your installer code.

22. Enter your Installer Code.

23. Press the ☞ ▸▸ or ◂ button repeatedly until the PowerMax10-G2 display reads [DEFINE COMM.] option.

24. When the PowerMax10-G2 display reads [DEFINE COMM.], press OK.

The PowerMax10-G2 display will read [1:PSTN/GSM]

25. When the PowerMax10-G2 display reads [1:PSTN/GSM] press the ▸▸ ◂ button until the display will read [2:GSM/GPRS]

26. Press OK.

The PowerMax10-G2 display will read [GPRS REPORT]. Here you determine whether the alarm system will report events to the Monitoring Station via the GPRS Channel.

27. When the PowerMax10-G2 display reads [GPRS REPORT T], press OK.

The PowerMax10-G2 display will read [disable ■].

28. Press the ▸▸ or ◂ button to select between "disable" and "enable", for example, "enable".

29. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [GPRS REPORT].

30. Press the ▸▸ button.

The PowerMax10-G2 display will read [GSM REPORT]. Here you determine whether the alarm system will report events to the Monitoring Station via the GSM Voice channel.

31. When the PowerMax10-G2 display reads [GSM REPORT], press OK.

The PowerMax10-G2 display will read [disable ■].

32. Press the ▸▸ or ◂ button to select between "disable" and "enable", for example, "enable".

33. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [GSM REPORT].

34. Press the ▸▸ button.

The PowerMax10-G2 display will read [SMS REPORT]. Here you determine whether the alarm system will report events to the Monitoring Station via the GPRS Channel.

35. When the PowerMax10-G2 display reads [SMS REPORT], press OK.

The PowerMax10-G2 display will read [disable ■].

36. Press the ▸▸ or ◂ button to select between "disable" and "enable", for example, "enable".

37. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [SMS REPORT].



38. Press the [▸▸] button.

The PowerMax10-G2 display will read [GPRS APN]

39. Enter the name of the APN Access Point used for the internet settings for the GPRS (up to 40 digits).

Note: *The table at the end of this section provides a list of the keys used by the PowerMax10-G2 editor.*

40. Press [i OK] to confirm.

The PowerMax10-G2 display will revert to [GPRS APN]

41. Press the [▸▸] button.

The PowerMax10-G2 display will read [GPRS USERNAME].

42. Enter the username of the APN used for GPRS communications (up to 30 digits).

Note: *The table at the end of this section provides a list of the keys used by the PowerMax10-G2 editor.*

43. Press [i OK] to confirm.

The PowerMax10-G2 display will revert to [GPRS USERNAME].

44. Press the [▸▸] button.

The PowerMax10-G2 display will read [GPRS PASSWORD].

45. Enter the password of the APN used for GPRS communications (up to 16 digits).

Note: *The table at the end of this section provides a list of the keys used by the PowerMax10-G2 editor.*

46. Press [i OK] to confirm.

The PowerMax10-G2 display will revert to [GPRS PASSWORD].

47. Press the [▸▸] button.

The PowerMax10-G2 display will read [PIN CODE].

48. Enter the PIN code of the SIM card installed in the PowerMax10-G2 unit (up to 16 digits).

49. Press [i OK] to confirm.

The PowerMax10-G2 display will revert to [PIN CODE].

50. Press the [▸▸] button.

The PowerMax10-G2 display will read [FORCE HOME NTWK.]. Here you determine whether to force the SIM card to use the home network only and not to select another network in case the home network cannot be found.

51. When the PowerMax10-G2 display reads [FORCE HOME NTWK.], press [i OK].

The PowerMax10-G2 display will read [disable ■].

52. Press the [▸▸] or [↩] button to select between "disable" and "enable", for example, "enable".

53. Press [i OK] to confirm the selection.

The PowerMax10-G2 display will revert to [FORCE HOME NTWK.].

54. Press the [▸▸] button.

The PowerMax10-G2 display will read [SESSION TIMEOUT]. Here you determine whether the control panel will stay continuously connected via GPRS

SMS REPORT

☞[▸▸]

GPRS APN

☞**APN NAME**

☞[i OK]

GPRS APN

☞[▸▸]

GPRS USERNAME

☞**APN USERNAME**

☞[i OK]

GPRS USERNAME

☞[▸▸]

GPRS PASSWORD

☞**APN PASSWORD**

☞[i OK]

GPRS PASSWORD

☞[▸▸]

PIN CODE

☞**PIN CODE**

☞[i OK]

PIN CODE

☞[▸▸]

FORCE HOME NTWK.

☞[i OK]

disable ■

☞[▸▸] **or** [↩]

enable

☞[i OK]

enable ■

FORCE HOME NTWK.

☞[▸▸]

SESSION TIMEOUT

communication, or, temporarily connected to receive event reports only.

55. When the PowerMax10-G2 display reads [SESSION TIMEOUT], press [OK].

The PowerMax10-G2 display will read [off on timeout ■].

56. Press the [▶▶] or [◀] button to select between "off on timeout" and "always ON", for example, "always ON ".

57. Press [OK] to confirm the selection.

The PowerMax10-G2 display will revert to [SESSION TIMEOUT].



You can now press the [▶▶] button to take you to the "GPRS REPORT" menu (see section 4.6.2.1), or press the [🔒] button to take you to "<OK> TO EXIT".

Key	Functionality
[▶▶]	Moves the cursor from left to right. Long press for speed.
[◀]	Moves the cursor from right to left. Long press for speed.
[2]	Scrolls upward the sequence of inserted digits. Long press for speed.
[8]	Scrolls downward the sequence of inserted digits. Long press for speed.
[#]	Places cursor to extreme right position of edit string and shows the last 16 digits of edit string.
[↑]	Reverts to previous or top menu without saving the edit string.
[🔒]	Reverts to "<OK> TO EXIT" without saving the edit string.
[OK]	Saves and reverts to previous menu.
[C]	Clears all digits to the right of cursor.
[0]	Clears one digit by cursor.
[5]	Selects between uppercase or lowercase digits.

4.6.3 Configuring Event Reporting to Monitoring Station.

Here you determine which types of event will be reported to Monitoring Stations. Due to lack of space in the display, abbreviations are used: alarm is "**alrm**", alert is "**alrt**" and open/close is "**o/c**". The asterisk (✳) is a separator between events reported to **Monitoring Station 1** and events reported to **Monitoring Station 2**.
Messages are divided by type into the following groups:

Group	Abbr.	Events Reported
Alarms	alrm	Fire, Burglary, Panic, Tamper
Open/close	o/c	Arming AWAY, Arming HOME, Disarming
Alerts	Alrt	No-activity, Emergency, Latchkey, Gas, Flood, Temperature
Maintenance	-	Low-battery AC failure

"Alarm" group has the highest priority and "Alert" group has the lowest priority.
The selectable options are as follows:

Plan name	Sent to center 1	Sent to center 2
"all -o/c ✳ backup"	All but open/close	All but open/close if center 1 doesn't respond
"all ✳ all"	All	All
"all-o/c ✳ all -o/c "	All but open/close	All but open/close
"all -o/c ✳ o/c "	All but open/close	Open/close
"all (-alrt) ✳ alrt"	All but alerts	Alerts
"alrm ✳ all (-alrm)"	Alarms	All but alarms
"disable report"	Nothing	Nothing
"all ✳ backup"	All	All if cent. 1 doesn't respond

***Note:** "All" means that all 4 groups are reported and also trouble messages - sensor / system low battery, sensor inactivity, power failure, jamming, communication failure etc.*

4.6.3.1 Configuring the Types of Events to be Reported

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Press the [▸▸] or [◂] button repeatedly until the PowerMax10-G2 display reads [DEFINE COMM.] option.

5. When the PowerMax10-G2 display reads [DEFINE COMM.], press [OK].

The PowerMax10-G2 display will read [1:PSTN/GSM].

6. When the PowerMax10-G2 display reads [1:PSTN/GSM], press the [▸▸] or [◂] button repeatedly until the display will read [3:C.S. REPORTING].

7. Press [OK].

The PowerMax10-G2 display will read [REPORT EVENTS].

8. When the PowerMax10-G2 display reads [REPORT EVENTS], press [OK].

The PowerMax10-G2 display will read [all-o/c* backup■].

9. Press the [▸▸] and [◂] buttons repeatedly to select between "all-o/c* backup", "all *all", "all-o/c*all-o/c", "all-o/c*o/c", "all(-alrt)*alrt", "alrm*all(-alrm)", "disable report" and "all *backup", for example, "all *backup".

10. Press [OK] to confirm the selection.

The PowerMax10-G2 display will revert to [REPORT EVENTS].



You can now press the [▸▸] button to take you to the "1st RPRT METHOD" menu, or press the [⌂] button to take you to "<OK> TO EXIT".

4.6.3.2 Configuring the Communicators Report Sequence

Continue below from the previous section or repeat steps 1 to 7 of section 4.6.3.1 before continuing with the following instructions.

11. Press the [▸▸] button.

The PowerMax10-G2 display will read [1st RPRT METHOD]. Here you define the 1st priority of method used to report events.

12. When the PowerMax10-G2 display reads [1st RPRT METHOD], press the [OK] button.

The PowerMax10-G2 display will read [disable ■].

13. Press the [▸▸] or [◂] button repeatedly to select between "disable", "cellular", "broadband" and "PSTN", for example, "PSTN".

14. Press [OK] to confirm the selection.

The PowerMax10-G2 display will revert to [1st RPRT METHOD].

15. Press the [▸▸] button.



The PowerMax10-G2 display will read [2nd RPRT METHOD]. Here you define the 2nd priority of method used to report events. If the method defined to report events in the 1st priority fails, the control panel will attempt to report using the method defined in the 2nd priority.

16. When the PowerMax10-G2 display reads [2nd RPRT METHOD], press the OK button.

The PowerMax10-G2 display will read [disable ■].



17. Press the ▶▶ or ◀ button repeatedly to select between "disable", "cellular", "broadband" and "PSTN", for example, "PSTN".

18. Press OK to confirm the selection.



The PowerMax10-G2 display will revert to [2nd RPRT METHOD].

19. Press the ▶▶ button.

The PowerMax10-G2 display will read [3rd RPRT METHOD]. Here you define the 3rd priority of method used to report events. If the method defined to report events in the 2nd priority fails, the control panel will attempt to report using the method defined in the 3rd priority.

20. When the PowerMax10-G2 display reads [3rd RPRT METHOD], press the OK button.

The PowerMax10-G2 display will read [disable ■].



21. Press the ▶▶ or ◀ button repeatedly to select between "disable", "cellular", "broadband" and "PSTN", for example, "PSTN".

22. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [3rd RPRT METHOD].

23. Press the ▶▶ button.

The PowerMax10-G2 display will read [DUAL REPORTING]. Here you determine whether to report events using PSTN and cellular at the same time instead of waiting for the 1st method to fail before trying the 2nd method.

24. When the PowerMax10-G2 display reads [DUAL REPORTING], press the OK button.

The PowerMax10-G2 display will read [disable ■].



25. Press the ▶▶ or ◀ button repeatedly to select between "disable", "PSTN & broadbnd" and "PSTN & cellular", for example, "PSTN & broadbnd".

26. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [DUAL REPORTING].

You can now press the ▶▶ button to take you to the "RCVR 1 ACCOUNT#" menu, or press the ⌂ button to take you to "<OK> TO EXIT".

4.6.3.3 Configuring Account Numbers to be Reported to the Monitoring Station

Continue below from the previous section or repeat steps 1 to 7 of section 4.6.3.1and then press the ▶▶ or ◀ button repeatedly until the PowerMax10-G2 display will read [RCVR 1 ACCOUNT#].

27. Press the ▶▶ button.

The PowerMax10-G2 display will read [RCVR 1 ACCOUNT#]. Here you enter the number that will identify your specific alarm control system to the 1st Monitoring Station. The number consists of 6 hexadecimal digits.

RCVR 1 ACCOUNT#

28. When the PowerMax10-G2 display reads [RCVR 1 ACCOUNT#], press the OK button.

☞OK

The PowerMax10-G2 display will read [1st acc. #001234].

1st acc. #001234

29. Enter the first receiver account number.

☞1st RCVR ACC. NO.

30. Press OK to confirm.

☞OK

The PowerMax10-G2 display will revert to [RCVR 1 ACCOUNT#].

RCVR 1 ACCOUNT#

31. Press the ▸▸ button.

☞▸▸

The PowerMax10-G2 display will read [RCVR 2 ACCOUNT#]. Here you enter the number that will identify your system to the 2nd Monitoring Station. The account number consists of 6 hexadecimal digits.

RCVR 2 ACCOUNT#

32. When the PowerMax10-G2 display reads [RCVR 2 ACCOUNT#], press the OK button.

☞OK

The PowerMax10-G2 display will read [2nd acc. #001234].

2nd acc. #001234

33. Enter the second receiver account number.

2nd RCVR ACC. NO.

34. Press the OK button.

☞OK

The PowerMax10-G2 display will revert to [RCVR 2 ACCOUNT#].

RCVR 2 ACCOUNT#

You can now press the ▸▸ button to take you to the "PSTN/GSM RCVR1" menu, or press the ⌂ button to take you to "<OK> TO EXIT".

4.6.3.4 Configuring the Monitoring Station's Telephone Numbers and IP Addresses

This mode allows you to adapt the telephone communication parameters to the local requirements.

Continue below from the previous section or repeat steps 1 to 7 of section 4.6.3.1and then press the ▸▸ or ↩ button repeatedly until the PowerMax10-G2 display will read [PSTN/GSM RCVR1].

35. Press the ▸▸ button.

☞▸▸

The PowerMax10-G2 display will read [PSTN/GSM RCVR1]. Here you program telephone number of the 1st Monitoring Station (including area code, 16 digit max) to which the system will report the event groups defined in Report Events.

PSTN/GSM RCVR1

36. When the PowerMax10-G2 display reads [PSTN/GSM RCVR1], press the OK button.

☞OK

37. Enter the telephone number of the first PSTN/GSM receiver (see table at the end of this section for further details).

■

38. Press the OK button.

☞OK

The PowerMax10-G2 display will revert to [PSTN/GSM RCVR1].

PSTN/GSM RCVR1

39. Press the ▸▸ button.

☞▸▸

The PowerMax10-G2 display will read [PSTN/GSM RCVR2]. Here you program telephone number of the 2nd Monitoring Station (including area code, 16 digit max) to which the system will report the event groups defined in Report Events.

PSTN/GSM RCVR2

40. When the PowerMax10-G2 display reads [PSTN/GSM RCVR2], press the OK button.

☞OK

41. Enter the telephone number of the second PSTN/GSM receiver (see table at the end of this section for further details).

■

42. Press the OK button.

☞OK

The PowerMax10-G2 display will revert to [PSTN/GSM RCVR2].

PSTN/GSM RCVR2

43. Press the ▸▸ button.

☞▸▸

The PowerMax10-G2 display will read [IP RCVR 1]. Here you enter the IP address of the IP receiver that is located in the 1st Monitoring Station.

IP RCVR 1

44. When the PowerMax10-G2 display reads [IP RCVR 1], press the OK button.

☞ OK

45. Enter the IP address of the first IP receiver (see table at the end of this section for further details).

000.000.000.000

46. Press the OK button.

☞ OK

The PowerMax10-G2 display will revert to [IP RCVR 1].

IP RCVR 1

47. Press the ▸▸ button.

☞ ▸▸

The PowerMax10-G2 display will read [IP RCVR2]. Here you enter the IP address of the IP receiver that is located in the 2nd Monitoring Station.

IP RCVR2

48. When the PowerMax10-G2 display reads [IP RCVR2], press the OK button.

☞ OK

49. Enter the IP address of the second IP receiver (see table at the end of this section for further details).

000.000.000.000

50. Press the OK button.

☞ OK

The PowerMax10-G2 display will revert to [IP RCVR2].

IP RCVR2

51. Press the ▸▸ button.

☞ ▸▸

The PowerMax10-G2 display will read [SMS RCVR 1]. Here you enter the telephone number of the SMS receiver that is located in the 1st Monitoring Station.

SMS RCVR 1

52. When the PowerMax10-G2 display reads [SMS RCVR 1], press the OK button.

☞ OK

53. Enter the telephone number of the first SMS receiver (see table at the end of this section for further details).

■

54. Press the OK button.

☞ OK

The PowerMax10-G2 display will revert to [SMS RCVR 1].

SMS RCVR 1

55. Press the ▸▸ button.

☞ ▸▸

The PowerMax10-G2 display will read [SMS RCVR2]. Here you enter the telephone number of the SMS receiver that is located in the 2nd Monitoring Station.

SMS RCVR2

56. When the PowerMax10-G2 display reads [SMS RCVR2], press the OK button.

☞ OK

57. Enter the telephone number of the second SMS receiver (see table at the end of this section for further details).

■

58. Press the OK button.

☞ OK

The PowerMax10-G2 display will revert to [SMS RCVR2].

SMS RCVR2

You can now press the ▸▸ button to take you to the "PSTN RPRT FORMAT" menu, or *press the ⌂ button to take you to "<OK> TO EXIT".*

Compatible Monitoring Station receivers are:
Osborne-Hoffman model 2000, Ademco Model 685, FBII Model CP220, Radionics Model D6500, Sur-Gard Model SG-MLR2-DG and Silent Knight Model 9500.

IMPORTANT: *In telephone number locations and account number locations, you may be required to enter hexadecimal digits. In telephone number locations, these digits are used as codes to control the dialer:*

Hex.Digit	*Keying Sequence*	*Code Significance*
A	**<#> ⇒ <0>**	*Applicable only at the beginning of a number - the dialer waits 10 seconds or waits for dial tone, whichever comes first and then dials.*
D	**<#> ⇒ <3>**	*Applicable only at the beginning of a number - the dialer waits 5 seconds for dial tone and goes on hook if none is received.*
E	**<#> ⇒ <4>**	*Applicable only in the middle of the number - the dialer waits 5 seconds*
F	**<#> ⇒ <5>**	*Not applicable in phone numbers*

***Note**: A "+" can be entered at the beginning of the line by pressing [#] and then [1].*

To enter a series of digits, use the following keys:
<Numeric keypad> - to enter the number
[▶▶] - moves the cursor from left to right
[◀] - moves the cursor from right to left
[🔒] - deletes everything after the cursor (to the right)

4.6.3.5 Configuring the Report Method (Protocol) to Monitoring Station

Continue below from the previous section or repeat steps 1 to 7 of section 4.6.3.1and then press the [▶▶] or [◀] button repeatedly until the PowerMax10-G2 display will read [PSTN RPRT FORMAT]

59. Press the [▶▶] button.

The PowerMax10-G2 display will read [PSTN RPRT FORMAT]. Here you select the reporting format used by the control panel to report events to Monitoring Stations.

60. When the PowerMax10-G2 display reads [PSTN RPRT FORMAT], press the [i OK] button.

The PowerMax10-G2 display will read [SIA ■].

61. Press the [▶▶] or [◀] button repeatedly to select between "SIA", "4/2 1900/1400", "4/2 1800/2300", "Scancom", "SIA text" and "contact ID", for example, "SIA text".



62. Press [i OK] to confirm the selection.

The PowerMax10-G2 display will revert to [PSTN RPRT FORMAT].

63. Press the [▶▶] button.



The PowerMax10-G2 display will read [4/2 PULSE RATE]. Here you select the pulse rate at which data will be sent to Monitoring Stations if any one of the 4/2 formats has been selected in PSTN Report Format.

64. When the PowerMax10-G2 display reads [4/2 PULSE RATE], press the [i OK] button.

The PowerMax10-G2 display will read [20 PPS ■].

65. Press the [▶▶] or [◀] button repeatedly to select between "10 PPS", "20 PPS", "33 PPS" and "40 PPS", for example, "40 PPS ".

66. Press [i OK] to confirm the selection.

The PowerMax10-G2 display will revert to [4/2 PULSE RATE].

You can now press the [▶▶] button to take you to the "PSTN RPRT RETRY" menu, or press the [🔒] button to take you to "<OK> TO EXIT".

4.6.3.6 Configuring the Number of Retry Attempts

Continue below from the previous section or repeat steps 1 to 7 of section 4.6.3.1and then press the [▶▶] or [◀] button repeatedly until the PowerMax10-G2 display will read [PSTN RPRT RETRY].

67. Press the [▶▶] button.

The PowerMax10-G2 display will read [PSTN RPRT RETRY]. Here you determine the number of times the communicator will dial the Monitoring Station's number via PSTN.

68. When the PowerMax10-G2 display reads [PSTN RPRT RETRY], press the [i OK] button.

The PowerMax10-G2 display will read [4 attempts ■].

69. Press the ▸▸ or ◂ button repeatedly to select between "2 attempts", "4 attempts", "8 attempts", "12 attempts" and "16 attempts", for example, "12 attempts".



70. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [PSTN RPRT RETRY].

71. Press the ▸▸ button.

The PowerMax10-G2 display will read [GSM RPRT RETRY]. Here you determine the number of times the communicator will try to report via a cellular group (GPRS, GSM and SMS) to the Monitoring Station.

72. When the PowerMax10-G2 display reads [GSM RPRT RETRY], press the OK button.

The PowerMax10-G2 display will read [4 attempts ■].

73. Press the ▸▸ or ◂ button repeatedly to select between "2 attempts", "4 attempts", "8 attempts", "12 attempts" and "16 attempts", for example, "12 attempts".



74. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [GSM RPRT RETRY].



75. Press the ▸▸ button.

The PowerMax10-G2 display will read [LAN RPRT RETRY]. Here you determine the number of times the communicator will try to report via the Broadband Module communication to the Monitoring Station.

76. When the PowerMax10-G2 display reads [LAN RPRT RETRY], press the OK button.

The PowerMax10-G2 display will read [4 attempts ■].

77. Press the ▸▸ or ◂ button repeatedly to select between "2 attempts", "4 attempts", "8 attempts", "12 attempts" and "16 attempts", for example, "12 attempts".



78. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [LAN RPRT RETRY].



You can now press the ▸▸ button to take you to the "AUTO TEST TIME" menu, or press the 🔒 button to take you to "<OK> TO EXIT".

4.6.3.7 Configuring the Auto Test Report

Continue below from the previous section or repeat steps 1 to 7 of section 4.6.3.1and then press the ▸▸ or ◂ button repeatedly until the PowerMax10-G2 display will read [AUTO TEST TIME]

79. Press the ▸▸ button.

The PowerMax10-G2 display will read [AUTO TEST TIME]. Here you determine the time at which the telephone line will be tested and reported to the Monitoring Station.

80. When the PowerMax10-G2 display reads [AUTO TEST TIME], press the OK button.

81. Enter the auto test time.



82. Press the [i OK] button.

The PowerMax10-G2 display will revert to [AUTO TEST TIME].

83. Press the [▸▸] button.

The PowerMax10-G2 display will read [AUTO TEST CYCLE]. Here you determine the time interval between consecutive telephone line test messages sent to the Monitoring Station. The control panel performs this at regular intervals to verify proper communications.

84. When the PowerMax10-G2 display reads [AUTO TEST CYCLE], press the [i OK] button.

The PowerMax10-G2 display will read [test OFF ■].

85. Press the [▸▸] or [◂] button repeatedly to select between "test OFF", "test every 1 d", "test every 2 d", "test every 5 d", "test every 7 d", "test every 14 d", "test every 30 d" and "test every 5 h", for example, "test every 5 d".

86. Press [i OK] to confirm the selection.

The PowerMax10-G2 display will revert to [AUTO TEST CYCLE].

87. Press the [▸▸] button.

The PowerMax10-G2 display will read [LINE FAIL REPORT].

88. Press the [i OK] button.

The PowerMax10-G2 display will read [PSTN]. Here you determine if the PSTN telephone line disconnection will be reported or not and determine the delay between detection of line disconnection and the failure reporting. If the telephone line is disconnected, the event "tel line fail" will be stored in the event log.

89. When the PowerMax10-G2 display reads [PSTN], press the [i OK] button.

The PowerMax10-G2 display will read [immediately ■].

90. Press the [▸▸] or [◂] button repeatedly to select between "immediately", "5 minutes", "30 minutes", "60 minutes", "180 minutes" and "don't report", for example, "60 minutes".

91. Press [i OK] to confirm the selection.

The PowerMax10-G2 display will revert to [PSTN].

92. Press the [▸▸] button.

The PowerMax10-G2 display will read [GSM/GPRS]. Here you determine if the GSM/GPRS line disconnection will be reported or not and determine the delay between detection of line disconnection and report failure. If the telephone line is disconnected, the event "GSM line fail" will be stored in the event log.

93. Press the [i OK] button.

The PowerMax10-G2 display will read [don't report ■].

94. Press the [▸▸] or [◂] button repeatedly to select between "2 minutes", "5 minutes", "30 minutes", "60 minutes", "180 minutes" and "don't report", for example, "30 minutes".

95. Press [i OK] to confirm the selection.

The PowerMax10-G2 display will revert to [GSM/GPRS].

96. Press the [▸▸] button.



The PowerMax10-G2 display will read [broadband]. Here you determine if the Broadband Module line disconnection will be reported or not and determine the delay between detection of line disconnection and report failure. If the telephone line is disconnected, the event "BBA line fail" will be stored in the event log.

broadband

97. Press the OK button.

The PowerMax10-G2 display will read [don't report ■].

☞ OK

don't report ■

98. Press the ▶▶ or ◀ button repeatedly to select between "2 minutes", "5 minutes", "30 minutes", "60 minutes", "180 minutes" and "don't report", for example, "30 minutes".

☞ ▶▶ or ◀

30 minutes

99. Press OK to confirm the selection.

☞ OK

30 minutes ■

The PowerMax10-G2 display will revert to [broadband].

broadband

100. Press the ⌂ button.

The PowerMax10-G2 display will revert to [LINE FAIL REPORT].

☞ ⌂

LINE FAIL REPORT

You can now press the ▶▶ button to take you to the "PSTN UP/DOWN" menu (see Configuring Remote Programming Access Permissions), or press the 🔒 button to take you to "<OK> TO EXIT".

4.6.3.8 Configuring the Event Types to be Reported to the Monitoring Station

Continue below from the previous section or repeat steps 1 to 7 of section 4.6.3.1and then press the ▶▶ or ◀ button repeatedly until the PowerMax10-G2 display will read [AUTO TEST TIME]

101. Press the ▶▶ button.

The PowerMax10-G2 display will read [RPRT CNFRM ALARM]. Here you determine whether the system will report whenever 2 or more events (**confirmed alarm)** occur during a specific period.

☞ ▶▶

RPRT CNFRM ALARM

102. Press the OK button.

The PowerMax10-G2 display will read [disable report].

☞ OK

disable report■

103. Press the ▶▶ or ◀ button repeatedly to select between "disable report", "enable + bypass" and "enable report", for example, "enable report".

☞ ▶▶ or ◀

enable report

104. Press OK to confirm the selection.

☞ OK

enable report ■

The PowerMax10-G2 display will revert to [RPRT CONFRM ALARM].

RPRT CONFRM ALARM

105. Press the ▶▶ button.

The PowerMax10-G2 display will read [RECENT CLOSE]. Here you enable or disable the "recent closing" report, that is sent to the Monitoring Station if an alarm occurs within 2 minutes from the expiry of the exit delay.

☞ ▶▶

RECENT CLOSE

106. When the PowerMax10-G2 display reads [RECENT CLOSE], press the OK button.

The PowerMax10-G2 display will read [recent cl. OFF ■].

☞ OK

recent cl. OFF ■

107. Press the ▶▶ or ◀ button to select between "recent cl. OFF" and "recent cl. ON", for example, "recent cl. ON".

☞ ▶▶ or ◀

recent cl. ON

108. Press OK to confirm the selection.

☞ OK

rem. access OFF■

The PowerMax10-G2 display will revert to [RECENT CLOSE].

RECENT CLOSE

109. Press the ▶▶ button.

The PowerMax10-G2 display will read [ZONE RESTORE]. Here you determine whether a zone restore will be reported or not.

110. When the PowerMax10-G2 display reads [ZONE RESTORE], press the OK button.

The PowerMax10-G2 display will read [report restore ■].

111. Press the ▶▶ or ◀ button to select between "report restore" and "don't report", for example, "don't report".

112. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [ZONE RESTORE].

113. Press the ▶▶ button.

The PowerMax10-G2 display will read [SYS INACT REPORT]. Here you determine whether the Monitoring Station will receive a message if the system is inactive (not armed) during a defined period (days).

114. Press the OK button.

The PowerMax10-G2 display will read [disable ■].

115. Press the ▶▶ or ◀ button repeatedly to select between "disable", "rep. after 7d", " rep. after 14d ", " rep. after 30d", and "rep. after 90d", for example, "rep. after 30d".

116. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [SYS INACT REPORT].

You can now press the ▶▶ button to take you to the "REPORT EVENTS" menu (see section 4.6.2.1), or press the 🔒 button to take you to "<OK> TO EXIT".

4.6.4 Configuring Event Reporting to Users

A. To Enable Report to Users

1. Make sure the system is disarmed and then press the ▶▶ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Press the ☞▶▶ or ◀ button repeatedly until the PowerMax10-G2 display reads [DEFINE COMM.] option.

5. When the PowerMax10-G2 display reads [DEFINE COMM.], press OK.

The PowerMax10-G2 display will read [1:PSTN/GSM].

6. When the PowerMax10-G2 display reads [1:PSTN/GSM], press the ▶▶ or ◀ button repeatedly until the display will read [4:PRIVATE REPORT].

7. Press OK.

The PowerMax10-G2 display will read [REPORT TO PRVT].



8. When the PowerMax10-G2 display reads [REPORT TO PRVT], press [OK].

The PowerMax10-G2 display will read [disable report■].

B. To Configure Event Types to be Reported to User

Here you determine which event groups will be reported to private telephone subscribers.

Term	Description
"all"	All messages
"all (-op/cl)"	All messages, except open/close
"all (-alerts)"	All messages, except alerts
"alarms"	Alarm messages
"alerts"	Alert messages
"op/cl"	Open/close
"disable report"	No message will be reported

Note: *"**All**" means all events including the L. BAT and AC FAIL trouble messages.*

Note: *All the above options can be reported to private telephone subscribers by SMS. When Voice Report is enabled alarms and alerts only can be reported.*

The following siren signal will be sent to private telephone upon event reporting:
FIRE: ON - ON - ON - pause.... (- - - - - - .....).
BURGLAR: ON continuously (▬▬▬▬▬...)
EMERGENCY/LATCHKEY: 2-tone siren; like an ambulance.

9. Press the [▸▸] and [↰] buttons repeatedly to select between "disable report", "all", "all (-op/cl)", "all(-alerts)", "alarms", "alerts" and "op/cl", for example, "all".

10. Press [OK] to confirm the selection.

The PowerMax10-G2 display will revert to [REPORT TO PRVT].



You can now press the [▸▸] button to take you to the "VOICE REPORT" menu (see the next section), or press the [🔒] button to take you to "<OK> TO EXIT".

C. To Configure Event Types to be Reported to User

11. Press the [▸▸] button.

The PowerMax10-G2 display will read [VOICE REPORT].

12. When the PowerMax10-G2 display reads [VOICE REPORT], press the [OK] button.

The PowerMax10-G2 display will read [1st private tel#].

13. Press the [OK] button and enter the first private telephone number (including area code, if required) of the private subscriber to which the system will report the event groups defined in Report To Private.

14. Press the [OK] button.

The PowerMax10-G2 display will revert to [1st private tel#].

15. Press the [▸▸] button.

The PowerMax10-G2 display will read [2nd private tel#].

16. Press the [OK] button and enter the second private telephone number (including area code, if required) of the private subscriber to which the system will report the event groups defined in Report To Private.

17. Press the [OK] button.

The PowerMax10-G2 display will revert to [2nd private tel#].

18. Press the [▸▸] button.

The PowerMax10-G2 display will read [3rd private tel#].

19. Press the OK button and enter the third private telephone number (including area code, if required) of the private subscriber to which the system will report the event groups defined in Report To Private.

☞OK

☞3rd PRVT TEL. NO

20. Press the OK button.

The PowerMax10-G2 display will revert to [3rd private tel#].

☞OK

3rd private tel#

21. Press the ▸▸ button.

The PowerMax10-G2 display will read [4th private tel#].

☞▸▸

4th private tel#

22. Press the OK button and enter the fourth private telephone number (including area code, if required) of the private subscriber to which the system will report the event groups defined in Report To Private.

☞OK

☞4th PRVT TEL. NO

23. Press the OK button.

The PowerMax10-G2 display will revert to [4th private tel#].

☞OK

4th private tel#

24. Press the ▸▸ button.

The PowerMax10-G2 display will read [Redial attempts]. Here you determine the number of times the communicator will dial the called party's number (private telephone).

☞▸▸

Redial attempts

25. When the PowerMax10-G2 display reads [Redial attempts], press the OK button.

The PowerMax10-G2 display will read [3 attempts ■].

☞OK

3 attempts ■

26. Press the ▸▸ or ◂ button repeatedly to select between "1 attempt", "2 attempts", "3 attempts" and "4 attempts", for example, "1 attempt".

Attention! *A maximum of 2 dialing attempts is permitted by the Australian Telecommunication Authority.*

☞▸▸ or ◂

1 attempt

27. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [Redial attempts].

☞OK

1 attempt ■

Redial attempts

28. Press the ▸▸ button.

The PowerMax10-G2 display will read [Tel. acknowledge]. Here you determine whether the system will use the single acknowledge or the all acknowledge mode when reporting to private telephones.

Note: *In the single acknowledge mode, receiving an acknowledge signal from a single telephone is sufficient to consider the current event closed and call off the communication session. The remaining telephones serve for backup purposes only. In the all acknowledge mode, an acknowledge signal must be received from each telephone before the current event is considered reported.*

☞▸▸

Tel. acknowledge

29. When the PowerMax10-G2 display reads [Tel. acknowledge], press the OK button.

The PowerMax10-G2 display will read [single ack ■].

☞OK

single ack ■

30. Press the ▸▸ or ◂ button to select between "single ack" and "all ack", for example, "all ack".

☞▸▸ or ◂

all ack

31. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [Tel. acknowledge].

☞OK

all ack ■

Tel. acknowledge

32. Press the ⌂ button

☞⌂

33. The PowerMax10-G2 display will revert to [VOICE REPORT].

VOICE REPORT

You can now press the [▸▸] button to take you to the "SMS REPORT TEL#" menu (see the next section), or press the [🔒] button to take you to "<OK> TO EXIT".

D. To Configure Reports to User by SMS

34. When the PowerMax10-G2 display reads [VOICE REPORT], press the [▸▸] button.

The PowerMax10-G2 display will read [SMS REPORT TEL#].

☞[▸▸]

SMS REPORT TEL#

35. When the PowerMax10-G2 display reads [SMS REPORT TEL#], press the [i OK] button.

The PowerMax10-G2 display will read [1st SMS tel#].

☞[i OK]

1st SMS tel#

36. Press the [i OK] button and enter the first SMS phone number (including area code, 16 digits maximum) to which pre-selected event types will be reported.

☞[i OK]

☞**1st SMS TEL. NO**

37. Press the [i OK] button.

The PowerMax10-G2 display will revert to [1st SMS tel#].

☞[i OK]

1st SMS tel#

38. Press the [▸▸] button.

The PowerMax10-G2 display will read [2nd SMS tel#].

☞[▸▸]

2nd SMS tel#

39. Press the [i OK] button and enter the second SMS phone number (including area code, 16 digits maximum) to which pre-selected event types will be reported.

☞[i OK]

☞**2nd SMS TEL. NO**

40. Press the [i OK] button.

The PowerMax10-G2 display will revert to [2nd SMS tel#].

☞[i OK]

2nd SMS tel#

41. Press the [▸▸] button.

The PowerMax10-G2 display will read [3rd SMS tel#].

☞[▸▸]

3rd SMS tel#

42. Press the [i OK] button and enter the third SMS phone number (including area code, 16 digits maximum) to which pre-selected event types will be reported.

☞[i OK]

☞**3rd SMS TEL. NO**

43. Press the [i OK] button.

The PowerMax10-G2 display will revert to [3rd SMS tel#].

☞[i OK]

3rd SMS tel#

44. Press the [▸▸] button.

The PowerMax10-G2 display will read [4th SMS tel#].

☞[▸▸]

4th SMS tel#

45. Press the [i OK] button and enter the fourth SMS phone number (including area code, 16 digits maximum) to which pre-selected event types will be reported.

☞[i OK]

☞**4th SMS TEL. NO**

46. Press the [i OK] button.

The PowerMax10-G2 display will revert to [4th SMS tel#].

☞[i OK]

4TH SMS tel#

*You can now press the [▸▸] button to take you to the "1st private tel#" menu (see step **C. To Configure Event Types to be Reported to User**), or press the [🔒] button to take you to "<OK> TO EXIT".*

4.7 Security System Configuration

4.7.1 Enable Cross Zoning

Cross Zoning

Here you determine whether cross zoning will be active or inactive. Cross zoning is a method used to counteract false alarms - an alarm will not be initiated unless two adjacent zones are violated within a 30-second time limit.

This feature is active only when arming AWAY and only with zone couples from zone No. 18 to 27 (18 and 19, 20 and 21, etc.). You may use any one of these zone couples to create a “cross-zoned” area.

***Note:** If one of two crossed zones is bypassed (see Para. 4.3.5), the remaining zone will function independently.*

Note: *Every 2 crossed zones must be of the allowed zone type (Interior, Perimeter, Perimeter follower).*
The options are: **cross zone ON** and **cross zone OFF** (default).

Cross zoning is not applicable in Entry/ Exit zones and 24h zones (Fire, Emergency, 24h audible, 24h silent).

To Enable Cross Zoning

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the ▸▸ or ◂ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▸▸ or ◂ button repeatedly until the display will read [14:CROSS ZONING].
7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [14:CROSS ZONING].

You can now press the ▸▸ or ◂ button to program any other menu in "DEFINE PANEL" or press the 🔒 button to take you to "<OK> TO EXIT".



4.7.2 Configuring Swinger Stop

Here you determine the number of times each zone is allowed to initiate an alarm within a single arming/disarming period (including tamper & power failure events of detectors, PowerMax10-G2, wireless siren, etc.). If the alarms number from a specific zone exceeds the programmed number, the control panel automatically bypasses the zone to prevent recurrent siren noise and nuisance reporting to the Monitoring Station. The zone will be reactivated upon disarming, or 48 hours after having been bypassed (if the system remains armed).

Available options are: **shut after 1** (default), **shut after 2** (default in USA), **shut after 3** and **no shutdown**.

To Configure Swinger Stop

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the ▸▸ or ◂ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▸▸ or ◂ button repeatedly until the display will read [13:SWINGER STOP].



7. Press [i OK] and make the selection and then press [i OK] to confirm.



The PowerMax10-G2 display will revert to [13:SWINGER STOP].

You can now press the [▸▸] or [↰] button to program any other menu in "DEFINE PANEL" or press the [🔒] button to take you to "<OK> TO EXIT".

4.7.3 Enable Monitoring of Activity at Home

Here you determine the time limit for reception of signals from sensors used to monitor the activity of sick, elderly or disabled people. If no sensor detects and reports movement at least once within the defined time limit, a "not-active" alert is initiated.

Options: **3**, **6**, **12**, **24**, **48**, **72 hours** and **no act disable** (default).

To Configure Monitoring of Activity at Home

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [i OK].
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the [▸▸] or [↰] button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press [i OK]
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the [▸▸] or [↰] button repeatedly until the display will read [21:NOT ACTIVE].
7. Press [i OK] and make the selection and then press [i OK] to confirm.



The PowerMax10-G2 display will revert to [21:NOT ACTIVE].

You can now press the [▸▸] or [↰] button to program any other menu in "DEFINE PANEL" or press the [🔒] button to take you to "<OK> TO EXIT".

4.7.4 Configuring Alarm Cancel Period

Here you determine the "cancel alarm" period that starts upon reporting an alarm to the Monitoring Station. If the user disarms the system within that time period, a "cancel alarm" message is sent to the Monitoring Station.

Available options are: **cancel time 1 m**, **cancel time 5 m** (default), **cancel time 15 m**, **cancel time 60 m**, **cancel time 4 hours** and also **cancel inactive** (default in USA).

Note: *To comply with CP-01 requirements, "1 minute" option is not available.*

To Configure the Alarm Cancel Period

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [i OK].
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.

4. Press the ▸▸ or ◂ button repeatedly and select the [DEFINE PANEL] option.

5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK

   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].

6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▸▸ or ◂ button repeatedly until the display will read [06:ALARM CANCEL].

7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [06:ALARM CANCEL].

You can now press the ▸▸ or ◂ button to program any other menu in "DEFINE PANEL" or press the ⌂ button to take you to "<OK> TO EXIT".



4.7.5 Configuring Power Failure Threshold Period

Here you determine the time interval between AC power failure occurrence and the failure reporting.
Options: **5 minutes** (default)**, 30 minutes, 60 minutes** or **180 minutes.**

Note: *To comply with EN requirements, set to 60 min. max.*

To Configure the Power Failure Threshold Period

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.

   The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Press the ▸▸ or ◂ button repeatedly and select the [DEFINE PANEL] option.

5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK

   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].

6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▸▸ or ◂ button repeatedly until the display will read [34:AC FAIL REP].

7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [34:AC FAIL REP].

You can now press the ▸▸ or ◂ button to program any other menu in "DEFINE PANEL" or press the ⌂ button to take you to "<OK> TO EXIT".



4.7.6 Configuring Abort Time

Here you select the length of time allowed by the system to abort an alarm (not applicable to alarms from FIRE, 24H SILENT, EMERGENCY, GAS, FLOOD and TEMPERATURE zones). The PowerMax10-G2 is programmed to provide an "abort interval" that starts upon detection of an event. During this interval, the buzzer sounds a warning but the siren remains inactive and the alarm is not reported. If the user disarms the system within the allowed abort interval, the alarm is aborted.

Available options are: **00s** (default in USA), **15s**, **30s** (default), **45s**, **60s**, **2m, 3m** and **4m**.
Note: *To comply with CP-01 requirements, "60s", "3m" and "4m" options are not available.*
Note: *To comply with UL requirements, the abort time must not exceed 45 sec.*

To Configure the Abort Time

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [i OK].
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the [▸▸] or [◂] buttons repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press [i OK]
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the [▸▸] or [◂] button repeatedly until the display will read [05:ABORT TIME].
7. Press [i OK] and make the selection and then press [i OK] to confirm.

   The PowerMax10-G2 display will revert to [05:ABORT TIME].

You can now press the [▸▸] or [◂] button to program any other menu in "DEFINE PANEL" or press the [⌂] button to take you to "<OK> TO EXIT".



4.7.7 Configuring a Confirmed Alarm

Here you determine that if 2 successive alarms will occur during a specific period, the second alarm will be considered as a **confirmed alarm** for confirmed alarm reporting, (see par. 4.6.3.2 "Configuring the Event Types to be Reported").
Options: **disable** (default in USA), **30 min.**, **45 min.**, **60 min.** (default), or **90 min.**

To Configure a Confirmed Alarm

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [i OK].
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the [▸▸] or [◂] button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press [i OK]
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the [▸▸] or [◂] button repeatedly until the display will read [33:CONFIRM TIME].
7. Press [i OK] and make the selection and then press [i OK] to confirm.



The PowerMax10-G2 display will revert to [33:CONFIRM TIME].

You can now press the ▶▶ or ◀ button to program any other menu in "DEFINE PANEL" or press the 🔒 button to take you to "<OK> TO EXIT".

4.7.8 Enable Alarm upon Detection of Jammed or Missing Device

Here you determine whether an alarm will be initiated (siren / report) when there is a supervision / jamming failure during AWAY arming state.
Available options are: **EN standard** and **other** (default). When "EN standard" is selected, if there is supervision / jamming failure during AWAY arming, the siren is activated and the events are reported as tamper events. When "Other" is selected, there is no such activity during AWAY arming.

To Enable an Alarm Upon Detection of a Jammed or Missing Device



1. Make sure the system is disarmed and then press the ▶▶ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the ▶▶ or ◀ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▶▶ or ◀ button repeatedly until the display will read [30:BELL/REP.OPT].
7. Press OK and make the selection and then press OK to confirm.

The PowerMax10-G2 display will revert to [30:BELL/REP.OPT].

You can now press the ▶▶ or ◀ button to program any other menu in "DEFINE PANEL" or press the 🔒 button to take you to "<OK> TO EXIT".

4.7.9 Configuring the Jamming Detection

Here you determine whether jamming (interfering transmissions, on the radio channel used by the system) will be detected and reported or not.
If a jam detection option is selected, the system does not allow arming under the relevant jamming conditions.
Jam Detection Options

Option	Detection and Reporting when
UL 20/20 (USA standard)	There is continuous 20 seconds of jamming
EN 30/60 (Europe standard)	There is an accumulated 30 seconds of jamming within 60 sec.
class 6 (30/60) (British standard)	Like EN (30/60) but the event will be reported only if the jamming duration exceeds 5 minutes.
Disable (default)	(No jamming detection and reporting).

To Configure the Jamming Detection

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the [▸▸] or [◂] button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press [OK]
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the [▸▸] [◂] button repeatedly until the display will read [19:JAM DETECT].

   You can now press the [▸▸] or [◂] button to program any other menu in "DEFINE PANEL" or press the [🔒] button to take you to "<OK> TO EXIT".
7. Press [OK] and make the selection and then press [OK] to confirm.

   The PowerMax10-G2 display will revert to [19:JAM DETECT].

   You can now press the [▸▸] or [◂] button to program any other menu in "DEFINE PANEL" or press the [🔒] button to take you to "<OK> TO EXIT".



4.7.10 Configuring Whether a Missing Device Causes the System to Become "NOT READY"

Here you determine if the system will be in NOT READY status when there is a supervision failure. In the "in supervision" mode, the system will be in NOT READY status if during the last 20 minutes a supervision message was not received. Options: **normal** (default) and **in supervision**.

Note: *To comply with EN requirements, "in supervision" must be selected.*

To Configure whether a missing device causes the system to become "NOT READY"

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the [▸▸] or [◂] button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press [OK]
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the [▸▸] or [◂] button repeatedly until the display will read [16:NOT READY].



7. Press [OK] and make the selection and then press [OK] to confirm.



The PowerMax10-G2 display will revert to [16:NOT READY].

You can now press the [▸▸] or [◂] button to program any other menu in "DEFINE PANEL" or press the [🔒] button to take you to "<OK> TO EXIT".

4.7.11 Configuring the Time Period by which a Device is considered Missing

Here you determine the time limit for reception of supervision reports from various supervised wireless devices. If any device does not report at least once within the selected time limit, an "INACTIVITY" alert is initiated.
The options are: **1**, **2**, **4**, **8**, **12 hours** (default) and **disable**.
Note: *To comply with EN requirements*, *1 or 2 hours must be selected.*

To Configure the Time Period by which a Device is Considered Missing

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the [▸▸] or [◂] button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press [OK]
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the [▸▸] or [◂] button repeatedly until the display will read [15:SUPERVISION].
7. Press [OK] and make the selection and then press [OK] to confirm.



The PowerMax10-G2 display will revert to [15:SUPERVISION].

You can now press the [▸▸] or [◂] button to program any other menu in "DEFINE PANEL" or press the [🔒] button to take you to "<OK> TO EXIT".

4.8 Arming/Disarming Options And Exit/Entry Delay

4.8.1 Configuring Exit Modes

Here you determine exit delay mode options. Three types of exit delay modes are available:
restart exit - Exit delay restarts when the door is reopened during exit delay. The restart occurs once only. Restarting the exit delay is helpful if the user re-enters immediately after going out to retrieve an item that he left behind.
off by door - When the door is closed, the exit delay is automatically terminated (even if the defined exit delay was not completed).
normal (default) - The exit delay is exactly as defined, regardless of whether the door is open or closed.

To Configure the Exit Modes

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].
   The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Press the ▶▶ or ◀ button repeatedly and select the [DEFINE PANEL] option.

5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK

   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].

6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▶▶ or ◀ button repeatedly until the display will read [09:EXIT MODE].

7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [09:EXIT MODE].



You can now press the ▶▶ or ◀ button to program any other menu in "DEFINE PANEL" or press the ⌂ button to take you to "<OK> TO EXIT".

4.8.2 Configuring Entry Delays Duration

Two different entry delays allow the user to enter the protected site (while the system is in the armed state) via 2 specific doors and routes without causing an alarm.

Following entry, the user must disarm the control panel before the entry delay expires. Slow-rate warning beeps start sounding once the door is opened, until the last 10 seconds of the delay, during which the beeping rate increases. Locations No. 1 (entry delay 1) and 2 (entry delay 2) allow you to program the length of these delays. Available options for each delay are: **"00s"**, "**15s**" (default for entry delay 2), "**30s**" (default for entry delay 1), "**45s**", "**60s**", "**3m**" and "**4m**".

Note: *To comply with CP-01 requirements, "00s" and "15s" options are not available.*

Note: *To comply with EN requirements, the entry delay must not exceed 45 sec.*

Note: *To comply with UL requirements, the entry delay must not exceed 15 sec.*

To Configure the Duration of the Entry Delays

1. Make sure the system is disarmed and then press the ▶▶ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.

   The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Press the ▶▶ or ◀ button repeatedly and select the [DEFINE PANEL] option.

5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK

   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].

6. Press the ▶▶ button once for [02:ENTRY DELAY 2].

7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [01:ENTRY DELAY 1].



You can now press the ▶▶ or ◀ button to program any other menu in "DEFINE PANEL" or press the ⌂ button to take you to "<OK> TO EXIT".

4.8.3 Configuring Exit Delay Duration

An exit delay allows the user to arm the system and leave the protected site via specific routes and doors without causing an alarm. Slow-rate warning beeps start sounding once the arming command has been given, until the last 10 seconds of the delay, during which the beeping rate increases. Location No. 3 allows programming of the exit delay length. Available options are: **30s, 60s** (default)**, 90s, 120s, 3m,** and **4m**.

Note: *To comply with CP-01 requirements, "30s" option is not available.*

Note: *To comply with UL requirements, the exit delay must not exceed 120 sec.*

To Configure the Exit Delay Duration

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the ▸▸ or ◂ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▸▸ or ◂ button repeatedly until the display will read [03:EXIT DELAY].
7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [03:BELL/REP.OPT].



You can now press the ▸▸ or ◂ button to program any other menu in "DEFINE PANEL" or press the ⌂ button to take you to "<OK> TO EXIT".

4.8.4 Enabling Quick Arm

Here you determine whether the user will be allowed to perform quick arming or not. Once quick arming is permitted, the control panel does not request a user code before it arms the system.

The two options are: **quick arm ON** (default in USA) and **quick arm OFF** (default).

To Enable Quick Arm

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the ▸▸ or ◂ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▸▸



or [◄] button repeatedly until the display will read [07:QUICK ARM].

7. Press [OK] and make the selection and then press [OK] to confirm.

The PowerMax10-G2 display will revert to [07:QUICK ARM].

You can now press the [►►] or [◄] button to program any other menu in "DEFINE PANEL" or press the [⌂] button to take you to "<OK> TO EXIT".



4.8.5 Configuring Bypassing Zones

Here you permit either manual bypassing of individual zones (through the USER SETTINGS menu), or allow the system to "force arm" (perform automatic bypassing) of open zones during the exit delay. If desired, press the arming key again if you want to eliminate the protest tone that sounds during forced arming. If a zone is open and forced arming is not permitted, "NOT READY" is displayed and the system does not arm (the "Sad Melody" will sound). If "no bypass" is selected, neither manual bypassing nor force arming is allowed.

Options: **manual bypass** (default in USA), **force arm** and **no bypass** (default).

Note: *To comply with EN requirements, "manual bypass" or "force arm" must be selected.*

Note: *The option "force arm" is not applicable in the UK.*

To Configure Bypass

1. Make sure the system is disarmed and then press the [►►] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Press the [►►] or [◄] button repeatedly and select the [DEFINE PANEL] option.

5. When the PowerMax10-G2 display reads [DEFINE PANEL], press [OK]

The PowerMax10-G2 display will read [01:ENTRY DELAY 1].

6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the [►►] or [◄] button repeatedly until the display will read [08:BYPASS].

7. Press [OK] and make the selection and then press [OK] to confirm.

The PowerMax10-G2 display will revert to [08:BYPASS].

You can now press the [►►] or [◄] button to program any other menu in "DEFINE PANEL" or press the [⌂] button to take you to "<OK> TO EXIT".



4.8.6 Configuring Panic Alarm Activation

Here you determine whether the user will be allowed to initiate a panic alarm by simultaneous pressing of either the two panic buttons (on the keypad / wireless commander) or away + home (on a keyfob transmitter). Audible panic activates the siren and simultaneously transmits a message via telephone. Silent panic only transmits a message via telephone.
The options are: **silent panic, audible panic** (default) and **disable panic**.

To Configure Panic Alarm Activation

1. Make sure the system is disarmed and then press the [►►] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the ▸▸ or ◂ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▸▸ or ◂ button repeatedly until the display will read [12:PANIC ALARM].
7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [12:PANIC ALARM].

You can now press the ▸▸ or ◂ button to program any other menu in "DEFINE PANEL" or press the 🔒 button to take you to "<OK> TO EXIT".



4.8.7 Enabling Latchkey Arming

Here you determine whether the system can be armed in the latchkey mode. If the system is armed this way, a "latchkey" message will be sent to specific telephones upon disarming by a "latchkey user" (users 5-8 or keyfob transmitters 5-8). This mode is useful when parents at work want to be informed of a child's return from school.

The options are: **Latchkey ON** and **Latchkey OFF** (default).

To Enable Latchkey Arming

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the ▸▸ or ◂ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the ▸▸ or ◂ button repeatedly until the display will read [20:LATCHKEY].
7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [20:LATCHKEY].

You can now press the ▸▸ or ◂ button to program any other menu in "DEFINE PANEL" or press the 🔒 button to take you to "<OK> TO EXIT".



4.9 User Interface Customization

4.9.1 Enabling Trouble Beeps

Under trouble conditions, the sounder emits a series of 3 short beeps once per minute. Here you determine whether this special beeping sequence will be active, inactive, or just inactive at night (the range of "night" hours is defined in the factory but is usually from 8 PM until 7 AM).
The 3 options are: **enable beeps** (default in USA), **off at night** (default) and **disable beeps**.

To Enable Trouble Beeps

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [i OK].
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Press the [▸▸] or [↰] button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press [i OK]
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], press the [▸▸] or [↰] button repeatedly until the display will read [11:TROUBLE BEEPS].
7. Press [i OK] and make the selection and then press [i OK] to confirm.
   The PowerMax10-G2 display will revert to [11:TROUBLE BEEPS].



You can now press the [▸▸] or [↰] button to program any other menu in "DEFINE PANEL" or press the [🔒] button to take you to "<OK> TO EXIT".

4.9.2 Enabling Piezo Beeps

Here you determine whether warning beeps will sound or muted during exit and entry delays. An additional option is to mute the warning beeps only when the system is armed "HOME".
Options: **enable beeps** (default), **off when home** (default in UPGM and **disable beeps**.
Note: *When exit beeps are disabled toward the end of a delay, the happy (success) melody will sound.*

To Enable Piezo Beeps

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [i OK].
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Click the [▸▸] or [↰] button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press [i OK]
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].



6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], click the ▶▶ or ◀ button repeatedly until the display will read [10:PIEZO BEEPS].

7. Press OK and make the selection and then press OK to confirm.

The PowerMax10-G2 display will revert to [10:PIEZO BEEPS].

You can now press the ▶▶ or ◀ button to program any other menu in "DEFINE PANEL" or press the 🔒 button to take you to "<OK> TO EXIT".



4.9.3 Enabling the Back Light

Here you determine whether the keypad back lighting will remain on at all times or will turn on when a key is pressed and turn off within 10 seconds if no further keystrokes are sensed.
The two options are: **always on** and **off after 10 s** (default).

To Enable the Back Light

1. Make sure the system is disarmed and then press the ▶▶ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Click the ▶▶ or ◀ button repeatedly and select the [DEFINE PANEL] option.

5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].

6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], click the ▶▶ or ◀ buttons repeatedly until the display will read [22:BACK LIGHT].

7. Press OK and make the selection and then press OK to confirm.

The PowerMax10-G2 display will revert to [22:BACK LIGHT].

You can now press the ▶▶ or ◀ button to program any other menu in "DEFINE PANEL" or press the 🔒 button to take you to "<OK> TO EXIT".



4.9.4 Configuring the Disarm Option

Here you determine when it is possible to disarm the system:
A. Any time.
B. In AWAY mode, during entry delay, by using the PowerMax10-G2 keypad or wireless sensor (keyfob).
C. In AWAY mode, during entry delay, by using a wireless device (keyfob) only (this is set as a default in UK to comply with DD243).
D. During entry delay, or by using the PowerMax10-G2 keypad in AWAY mode.
Options: **any time** (default), **on entry all**, **on entry wireless**, or **entry + away kp** (default in UK).

To Configure the Disarm Option

1. Make sure the system is disarmed and then press the ▶▶ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Click the ▶▶ or ◀ button repeatedly and select the [DEFINE PANEL] option.

5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK

   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].

6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], click the ▶▶ or ◀ button repeatedly until the display will read [29:DISARM OPTION].

7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [29:DISARM OPTION].



You can now press the ▶▶ or ◀ button to program any other menu in "DEFINE PANEL" or press the 🔒 button to take you to "<OK> TO EXIT".

4.9.5 Configuring the Screen Saver Options

Here you can determine that if no key is pressed during more than 30 seconds the display will read "PowerMax" (to prevent a possible intruder of knowing the system status). You can determine that normal display will return after pressing the 🔓 button followed by entering user code (**Refresh by Code**) or after pressing any key (**Refresh by Key**).

If **Refresh by Key** is selected, the first pressing of any key (except Fire and Emergency) will cause normal display return and the second press will perform the key function. Regarding the Fire and Emergency keys, the first key press will cause normal display return and also will perform the Fire/Emergency function.

Options: **scrn saver OFF** (default), **refresh by code**, **refresh by key**.

Note: *To comply with EN requirements, "refresh by code" must be selected.*

To Configure the Screen Saver Option

1. Make sure the system is disarmed and then press the ▶▶ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.

   The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

4. Click the ▶▶ or ◀ button repeatedly and select the [DEFINE PANEL] option.

5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK

   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].

6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], click the ▶▶ or ◀ button repeatedly until the display will read [32:SCREEN SAVER].

7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [32:SCREEN SAVER].



You can now press the ▶▶ or ◀ button to program any other menu in "DEFINE PANEL" or press the 🔒 button to take you to "<OK> TO EXIT".

4.9.6 Enabling the Memory Prompt

Here you determine whether the user will receive indication that an alarm has been activated.
Available options are: **enable** (default) and **disable**.

To Enable the Memory Prompt

1. Make sure the system is disarmed and then press the ▶▶ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Click the ▶▶ or ◀ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], click the ▶▶ or ◀ button repeatedly until the display will read [28:MEMORY PROMPT].
7. Press OK and make the selection and then press OK to confirm.

   The PowerMax10-G2 display will revert to [28:MEMORY PROMPT].



You can now press the ▶▶ or ◀ button to program any other menu in "DEFINE PANEL" or press the 🔒 button to take you to "<OK> TO EXIT".

4.9.7 Enabling Keyfob Low Battery Acknowledgement

Here you determine whether the user will hear or will not hear low battery sound when he tries to disarm the system with a keyfob whose battery voltage is low.
Available options are: **keyfob L-B on** - the user has to acknowledge the keyfob low battery message, or, **keyfob L-B off** (default) - the user does not have to acknowledge the keyfob low battery message.

To Enable Keyfob Low Battery Acknowledgement

1. Make sure the system is disarmed and then press the ▶▶ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".
2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.
   The screen will now prompt you to enter your installer code.
3. Enter your Installer Code.
4. Click the ▶▶ or ◀ button repeatedly and select the [DEFINE PANEL] option.
5. When the PowerMax10-G2 display reads [DEFINE PANEL], press OK
   The PowerMax10-G2 display will read [01:ENTRY DELAY 1].
6. When the PowerMax10-G2 display reads [01:ENTRY DELAY 1], click the



or button repeatedly until the display will read [31:LOW-BAT ACK].

31:LOW-BAT ACK

7. Press OK and make the selection and then press OK to confirm.

☞ OK

☞ **SELECT OPTION**

☞ OK

The PowerMax10-G2 display will revert to [31:LOW-BAT.ACK].

31:LOW-BAT ACK

You can now press the or button to program any other menu in "DEFINE PANEL" or press the button to take you to "<OK> TO EXIT".

4.10 DEFINE CUSTOM LOCATIONS

This mode allows you to define up to 5 locations (in addition to the locations that can be defined in the ZONES / DEVICES mode - see par. 4.4).

To Define Custom Locations

1. Make sure the system is disarmed and then press the button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

READY 00:00

☞

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.

INSTALLER MODE

☞ OK

The screen will now prompt you to enter your installer code.

ENTER CODE: ■

3. Enter your Installer Code.

☞**CODE**

The PowerMax10-G2 display will read [NEW INSTL CODE].

NEW INSTL CODE

4. When the PowerMax10-G2 display reads [NEW INSTL CODE] press the or button repeatedly until the PowerMax10-G2 display will read [DEFINE CUSTOM].

☞ or

DEFINE CUSTOM

5. Press the OK button.

☞ OK

The PowerMax10-G2 display will read [CUST. ZONES NAME].

CUST. ZONES NAME

6. When the PowerMax10-G2 display reads [CUST. ZONES NAME], press the OK button.

☞ OK

The PowerMax10-G2 display will read [EDIT USER TERM 1].

EDIT USER TERM 1

7. Press the OK button. The PowerMax10-G2 display will read [Custom 1].

☞ OK

***Note:** The table at the end of this section provides a list of the keys used by the PowerMax10-G2 editor.*

Custom 1

8. Press the OK button to confirm the location definition.

☞ OK

EDIT USER TERM 1

Press the or button and repeat the procedure for [EDIT USER TERM 2] - –EDIT USER TERM 5], as required.

Pressing the or buttons at any stage in the procedure will take you to "<OK> TO EXIT".

Key	Functionality
▶▶	Moves the cursor from left to right. Long press for speed.
◀	Moves the cursor from right to left. Long press for speed.
2	Scrolls upward the sequence of inserted digits. Long press for speed.
8	Scrolls downward the sequence of inserted digits.

Key	Functionality
	Long press for speed.
#	Places cursor to extreme right position of edit string and shows the last 16 digits of edit string.
	Reverts to previous or top menu without saving the edit string.
	Reverts to "<OK> TO EXIT" without saving the edit string.
OK	Saves and reverts to previous menu.
	Clears all digits to the right of cursor.
0	Clears one digit by cursor.
5	Selects between uppercase or lowercase digits.

4.11 CONFIGURING OUTPUT PARAMETERS

4.11.1 Preliminary Guidance

This mode allows you:

a. Events/conditions selection under which PGM (programmable) output will function.
b. Selection of the internal siren or STROBE light (that will be activated according to system programming).

4.11.2 Define PGM

For the PGM output, you can select **disable, turn on**, **turn off** or **pulse active** (turn on for predefined period, selected by **PULSE TIME**), as follows:

- **ARM AWAY** (upon AWAY arming).
- **ARM HOME** (upon HOME arming).
- **DISARM** (upon disarming).
- **MEMORY** (activated upon registration of an alarm in the memory, turned off upon memory clearing).
- **DELAY** (during exit / entry delays).
- **KEYFOB** (upon AUX button pressing in the keyfob transmitter).
- **ZONES** (by disturbance in each of 3 selected zones, irrespective of arming / disarming). If you select **toggle**, the PGM output will be turned on upon event occurrence in these zones and will be turned off upon next event occurrence, alternately.
- **LINE FAIL:** PGM output is ON if telephone line is disconnected.

For PGM devices, you can select the following actions:

- **FLASH ON ALARM** - you can select **no flash** or **all light flash**, to control PGM lighting devices in alarm conditions.
- **LOCKOUT TIME** - you can enter daytime limits between which PGM lighting devices controlled by sensors will be off, even when the associated sensors are triggered.

A. To Configure Output Parameters

1. Make sure the system is disarmed and then press the button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

READY 00:00

☞

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.

INSTALLER MODE

☞OK

The screen will now prompt you to enter your installer code.

ENTER CODE: ■

3. Enter your Installer Code.

☞**CODE**

The PowerMax10-G2 display will read [NEW INSTL CODE].

NEW INSTL CODE

Note: *The installer code should never be programmed as "0000". Doing so will lock the user out of the installer menu!*

4. When the PowerMax10-G2 display reads [NEW INSTL CODE] click the or button repeatedly until the PowerMax10-G2 display will read [DEFINE OUTPUTS].

☞ or

DEFINE OUTPUTS

5. Press the OK button.

☞OK

There are two sub-menus [DEFINE PGM] and [PGM GENERAL DEF].

The PowerMax10-G2 display will first read [DEFINE PGM].

DEFINE PGM

6. When the PowerMax10-G2 display reads [DEFINE PGM], press the OK button.

☞OK

The PowerMax10-G2 display will read [PGM: PULSE TIME].

7. When the PowerMax10-G2 display reads [PGM: PULSE TIME], press the OK button.

The PowerMax10-G2 display will read [pulse time 2s ■].

8. Press the ▸▸ or ↰ button repeatedly to select between "pulse time 2s", "pulse time 30s", "pulse time 2m" and "pulse time 4m", for example, "pulse time 30s".

9. Press OK to make the selection.

10. Press OK again to confirm.

The PowerMax10-G2 display will read [PGM: BY ARM AWAY].

11. When the PowerMax10-G2 display reads [PGM: BY ARM AWAY], press the OK button.

The PowerMax10-G2 display will read [disable ■].

12. Press the ▸▸ or ↰ button repeatedly to select between "disable", "turn ON", "turn OFF" and "pulse active", for example, "pulse active".

13. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [PGM: BY ARM AWAY].

14. Press the ▸▸ button.

The PowerMax10-G2 display will read [PGM: BY ARM HOME].

15. When the PowerMax10-G2 display reads [PGM: BY ARM HOME], press the OK button.

The PowerMax10-G2 display will read [disable ■].

16. Press the ▸▸ or ↰ button repeatedly to select between "disable", "turn ON", "turn OFF" and "pulse active", for example, "pulse active".

17. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [PGM: BY ARM HOME].

18. Press the ▸▸ button.

The PowerMax10-G2 display will read [PGM: BY DISARM].

19. When the PowerMax10-G2 display reads [PGM: BY DISARM], press the OK button.

The PowerMax10-G2 display will read [disable ■].

20. Press the ▸▸ or ↰ button repeatedly to select between "disable", "turn ON", "turn OFF" and "pulse active", for example, "pulse active".

21. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [PGM: BY DISARM].

22. Press the ▸▸ button.



The PowerMax10-G2 display will read [PGM: BY MEMORY].

23. When the PowerMax10-G2 display reads [PGM: BY MEMORY], press the OK button.

The PowerMax10-G2 display will read [disable ■].

24. Press the ▸▸ or ↰ button repeatedly to select between "disable", "turn ON", "turn OFF" and "pulse active", for example, "pulse active".

25. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [PGM: BY MEMORY].

26. Press the ▸▸ button.

The PowerMax10-G2 display will read [PGM: BY DELAY].

27. When the PowerMax10-G2 display reads [PGM: BY DELAY], press the OK button.

The PowerMax10-G2 display will read [disable ■].

28. Press the ▸▸ or ↰ button repeatedly to select between "disable", "turn ON", "turn OFF" and "pulse active", for example, "pulse active".

29. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [PGM: BY DELAY].

30. Press the ▸▸ button.

The PowerMax10-G2 display will read [PGM: BY KEYFOB].

31. When the PowerMax10-G2 display reads [PGM: BY KEYFOB], press the OK button.

The PowerMax10-G2 display will read [disable ■].

32. Press the ▸▸ or ↰ button repeatedly to select between "disable", "turn ON", "turn OFF", "pulse active" and "toggle" for example, "toggle".

33. Press OK to confirm the selection.

The PowerMax10-G2 display will revert to [PGM: BY KEYFOB].

34. Press the ▸▸ button.

The PowerMax10-G2 display will read [PGM: BY ZONES].

35. When the PowerMax10-G2 display reads [PGM: BY ZONES], press the OK button.

The PowerMax10-G2 display will read [a – zone].

36. Press the OK button.

The PowerMax10-G2 display will read [a – zone Z:00].

37. Enter the number of the first zone that you designate for activating this output, for example, " a – zone Z:11" and then press the OK button.

38. Press OK again to confirm.



The PowerMax10-G2 display will read [disable ■].



39. Press the ▶▶ and ↩ buttons repeatedly to select between "disable", "turn ON", "turn OFF", "pulse active" and "toggle", for example, "toggle".

40. Press OK to make the selection.

41. Press OK again to confirm.

The PowerMax10-G2 display will revert to [a – zone].

42. Press the ▶▶ button.

The PowerMax10-G2 display will read [b – zone].

43. Repeat steps 42 through to 47 for the second zone. When done, the display will revert to [b – zone].

44. Press the ▶▶ button.

The PowerMax10-G2 display will read [c – zone].

45. Repeat steps 42 through to 47 for the third zone. When done, the display will revert to [c – zone].



46. Press the ⌂ button.

The PowerMax10-G2 display will revert to [PGM: BY ZONES].

47. Press the ▶▶ button.

The PowerMax10-G2 display will read [PGM BY LINE FAIL].

48. When the PowerMax10-G2 display reads [PGM BY LINE FAIL], press the OK button.

The PowerMax10-G2 display will read [by line fail NO■].

49. Press the ▶▶ or ↩ button to select between "by line fail NO" and "by line failYES" for example, "by line failYES".



50. Press OK to confirm the selection.



The PowerMax10-G2 display will revert to [PGM BY LINE FAIL].



Clicking the ⌂ or 🔒 buttons at any stage in the procedure will take you to "<OK> TO EXIT".

B. To Configure PGM Lighting Devices in Alarm Conditions and To Set Daytime Limits of Lighting Devices

1. Repeat steps **1.** to **5.** of the previous section, **"A. To Configure Output Parameters"**.

2. When the PowerMax10-G2 display reads [DEFINE PGM], press the ▶▶ button.

The PowerMax10-G2 display will read [PGM GENERAL DEF].



3. When the PowerMax10-G2 display reads [PGM GENERAL DEF], press the OK button.

The PowerMax10-G2 display will read [FLASH ON ALARM].

4. When the PowerMax10-G2 display reads [FLASH ON ALARM], press the OK button.

The PowerMax10-G2 display will read [no flash ■].

5. Press the [▸▸] or [◂] button to select between "no flash" and "all light flash", for example, "all light flash".



6. Press [OK] to confirm the selection.

7. Press [OK] again to confirm.

The PowerMax10-G2 display will revert to [FLASH ON ALARM].

8. Press the [▸▸] button.

The PowerMax10-G2 display will read [LOCKOUT TIME].



9. When the PowerMax10-G2 display reads [LOCKOUT TIME], press the [OK] button.

The PowerMax10-G2 display will read [start- HH:MM].

10. Press the [OK] button.

The PowerMax10-G2 display will change to [TIME 07:00A]

11. Enter the time at which you wish the lockout state to begin (usually at dawn).

Note: *AM and PM are selected by pressing [*] and [#], respectively.*



12. Press the [OK] button.

The PowerMax10-G2 display will revert to [start- HH:MM].



13. Press the [▸▸] button.

The PowerMax10-G2 display will read [stop- HH:MM].

14. Press the [OK] button.

The PowerMax10-G2 display will change to [TIME 07:00P]

15. Enter the time at which you wish the lockout state to end (usually in the evening).

Note: *AM and PM are selected by pressing [*] and [#], respectively.*



16. Press the [OK] button.

The PowerMax10-G2 display will revert to [stop- HH:MM].

Pressing the [⌂] or [🔒] buttons at any stage in the procedure will take you to "<OK> TO EXIT".

4.12 Programming User Settings

This mode provides you with a gateway to the user functions through the regular user programming menu.

To Set User Codes

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

The PowerMax10-G2 display will read [NEW INSTL CODE].

4. When the PowerMax10-G2 display reads [NEW INSTL CODE] press the [▸▸] or [◂] button repeatedly until the PowerMax10-G2 display will read [USER SETTINGS].

5. When the PowerMax10-G2 display reads [USER SETTINGS] press [OK]

The PowerMax10-G2 display will read [USER CODES].



6. Press [OK]. The PowerMax10-G2 display will read [user code 1].

7. Press [OK] and enter the 4-digit user code, for example, 6854.

8. Press [OK] to confirm.

The PowerMax10-G2 display reads [user code 1].
A "Happy Tune" ♫☺ sounds. The display confirms the saved code.
Press the [▸▸] button and repeat the procedure for User Codes 2 - 8.
Clicking the [⌂] or [🔒] buttons at any stage in the procedure will take you to "<OK> TO EXIT".

Caution! If after having programmed the user codes the system does not recognize your installer code, this indicates you must have programmed a user code that is identical with your installer code. If so, access the user menu and change the code that is identical with your installer code. This will re-validate your installer code.

Configuring Remote Programming Access Permissions

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [OK].

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

☞**CODE**

4. Press the ☞[▸▸] or [◂] button repeatedly until the PowerMax10-G2 display reads [DEFINE COMM.] option.

☞▸▸ **or** ◂

5. When the PowerMax10-G2 display reads [DEFINE COMM.], press [OK].

The PowerMax10-G2 display will read [1:PSTN/GSM].



6. When the PowerMax10-G2 display reads [1:PSTN/GSM], press the [▸▸] or [◂] button repeatedly until the display will read [3:Monitoring Station. REPORTING].

7. Press [OK].

The PowerMax10-G2 display will read [REPORT EVENTS].



8. When the PowerMax10-G2 display reads [REPORT EVENTS], press the [▸▸] or [◂] button repeatedly until the display will read [PSTN UP/DOWN].

9. Press the [OK] button.

The PowerMax10-G2 display will read [Remote access]. Here you give or deny permission to access the system and exercise control from a remote telephone.

10. When the PowerMax10-G2 display reads [Remote access], press the [OK] button.

The PowerMax10-G2 display will read [rem. access ON ■].

11. Press the [▸▸] or [◂] button to select between "rem. access ON" and "rem. access OFF", for example, "rem. access OFF".



12. Press [OK] to confirm the selection.

The PowerMax10-G2 display will revert to [Remote access].

Remote access

13. Press the [▸▸] button.

The PowerMax10-G2 display will read [Mast. downl code]. Here you determine the master installer 4-digit password for downloading/uploading data into/from the PowerMax10-G2 memory.

Attention! If "0000" is used, it will not enable connection of the PowerMax10-G2 to the PC for upload/download purpose.

Mast. Downl code

14. When the PowerMax10-G2 display reads [Mast. downl code], press the [OK] button.

15. Enter the 4-digit master download code ("0000" is not a valid code).

downl. Code AAAA

16. Press the [OK] button.

The PowerMax10-G2 display will revert to [Mast. Downl code].

Mast. downl code

17. Press the [▸▸] button.

The PowerMax10-G2 display will read [Inst. downl code]. Here you determine the installer 4-digit password for downloading data into the PowerMax10-G2 memory.

Attention! If "0000" is used, it will not enable connection of the PowerMax10-G2 to the PC for upload/download purpose.

Inst. Downl code

18. When the PowerMax10-G2 display reads [Inst. downl code], press the [OK] button.

19. Enter the 4-digit installer download code ("0000" is not a valid code).

downl. Code BBBB

20. Press the [OK] button twice.

The PowerMax10-G2 display will revert to [Inst. downl code].

Inst. downl code

21. Press the [▸▸] button.

The PowerMax10-G2 display will read [Upload option]. Here you determine whether the PowerMax10-G2 data can be uploaded into a computer while the system is in disarm state or at any time (in HOME/AWAY arming & disarm state).

Upload option

22. When the PowerMax10-G2 display reads [Upload option], press the [OK] button.

The PowerMax10-G2 display will read [any time ■].

any time ■

23. Press the [▸▸] or [↰] button to select between "any time" and "when system OFF", for example, "when system OFF".

when system OFF

24. Press [OK] to confirm the selection.

when system OFF■

The PowerMax10-G2 display will revert to [Upload option].

Upload option

25. Press the [▸▸] button.

The PowerMax10-G2 display will read [Up/download tel#]. Here you enter the telephone number (up to 16 digits) of the UL/DL server.

Note: *Only for use with control panels monitored by compatible Monitoring Stations. Leave empty if not used.*

Up/download tel#

26. When the PowerMax10-G2 display reads [Up/download tel#], press the [OK] button.

27. Enter the upload/download software telephone number.

■

28. Press the [OK] button twice.

The PowerMax10-G2 display will revert to [Up/download tel#].

Up/download tel#

29. Press the [⌂] button.

The PowerMax10-G2 display will revert to [PSTN UP / DOWN].

PSTN UP / DOWN

30. Press the ▸▸ button.

☞▸▸

The PowerMax10-G2 display will read [GPRS UP / DOWN].

GPRS UP / DOWN

31. Press the OK button.

☞OK

The PowerMax10-G2 display will read [My SIM Tel.#]. Here you enter the PowerMax10-G2 SIM card telephone number. The Monitoring Station dials this number when it needs to connect to the PowerMax10-G2 for uploading / downloading data.

My SIM Tel.#

32. When the PowerMax10-G2 display reads [My SIM Tel.#], press the OK button.

☞OK

33. Enter the SIM card telephone number.

■

34. Press the OK button twice.

☞OK OK

The PowerMax10-G2 display will revert to [My SIM Tel.#].

My SIM Tel.#

35. Press the ▸▸ button.

☞▸▸

The PowerMax10-G2 display will read [1st caller ID#]. Here you determine the 1st IPMP receiver telephone number. When the PowerMax10-G2 responds to an incoming call from the telephone number defined here, it creates a connection to the IPMP for uploading / downloading data.

Note: *caller ID#1 / ID#2 should be 6 or more digits for wake-up by IPMP to work.*

1st caller ID#

36. When the PowerMax10-G2 display reads [1st caller ID#], press the OK button..

☞OK

37. Enter the first IP receiver telephone number.

■

38. Press the OK button twice.

☞OK OK

The PowerMax10-G2 display will revert to [1st caller ID#].

1st caller ID#

39. Press the ▸▸ button.

☞▸▸

The PowerMax10-G2 display will read [2nd caller ID#]. Here you determine the 2nd IPMP receiver telephone number. When the PowerMax10-G2 responds to an incoming call from the telephone number defined here, it creates a connection to that IPMP for uploading / downloading data.

2nd caller ID#

40. When the PowerMax10-G2 display reads [2nd caller ID#], press the OK button.

☞OK

41. Enter the second IP receiver telephone number.

■

42. Press the OK button twice.

☞OK OK

The PowerMax10-G2 display will revert to [2nd caller ID#].

2nd caller ID#

43. Press the ⌂ button.

☞⌂

The PowerMax10-G2 display will revert to [GPRS UP / DOWN].

GPRS UP / DOWN

You can now press the ▸▸ button to take you to the "RPRT CNFRM ALARM" menu (see section 4.6.3.8), or *press the 🔔 button to take you to "<OK> TO EXIT".*

5 DIAGNOSTIC TEST

This mode allows you to test the functionality of all devices of the system and to receive / review information regarding the received signal strength. Communication between system components can also be tested and detailed information is reported.

The wireless signal strength measured and reported (see details in the drawing below).

IMPORTANT! *Reliable reception must be assured during the initial testing and also throughout subsequent system maintenance. A* ***device should not be installed in location where signal strength is "poor" or "bad".*** *If you get a "poor"/"bad" signal strength from a certain device, simply re-locate it and re-test until a "good" or "strong" signal strength is received. This principle should be followed throughout the diagnostic test procedure.*

The diagnostic test process is shown below.

5.1 Testing Devices

This section describes how to test or review a device enrolled to the PowerMax10-G2 control panel.

Note:

It is much easier to test the device while holding the device in your hand, close to the control panel.

5.1.1 Testing all Devices

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [i OK].

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.
The PowerMax10-G2 display will read [NEW INSTL CODE].

☞**CODE**

4. When the PowerMax10-G2 display reads [NEW INSTL CODE] press the [▸▸] or [↩] button repeatedly until the PowerMax10-G2 display will read [DIAGNOSTICS].

☞[▸▸] or [↩]

5. When the PowerMax10-G2 display reads [DIAGNOSTICS], press the [i OK] button.

The PowerMax10-G2 display will read [WL DEVICES].*

☞[i OK]

6. When the PowerMax10-G2 display reads [WL DEVICES], press the [i OK] button.

The PowerMax10-G2 display will read [TEST ALL DEVICES].



☞[i OK]

7. When the PowerMax10-G2 display reads [TEST ALL DEVICES], press the [i OK] button (or press the [▸▸] button for [TEST ONE DEVICE]).

☞[i OK]

The PowerMax10-G2 system will now perform automatic testing of all enrolled devices in the following order: repeaters, sirens, detectors, keypads.

The PowerMax10-G2 system will perform automatic testing of keyfobs (if enrolled) at the end of testing all other devices.

***Note:** "Zxx" indicates the type of device and device number that is being tested. "NNN" indicates the number of devices that have not yet been tested.*



At this stage if any key is pressed the PowerMax10-G2 display will read [<NEXT> TO END] alternating with [<OK> TO CONTINUE]. Press the [▸▸] button to stop the current test and jump to the next test, or, press the [i OK] button to continue the test, or, press the [🔒] button to exit.



or

At the end of the testing procedure the PowerMax10-G2 display will read [SHOW ALL DEVICES].

* *If there are no wireless devices enrolled in the PowerMax10-G2 system, the PowerMax10-G2 display reads [NO DEVICES].*

Pressing the [⌂] or [🔒] buttons at any stage in the procedure will take you to "<NEXT> TO END" or "<OK> TO EXIT".

5.1.2 Testing One Device

1. Repeat steps 1 to 6 from section 5.1.1 Testing all Devices.

2. When the PowerMax10-G2 display reads [TEST ALL DEVICES], press the [▸▸] button.

The PowerMax10-G2 display will read [TEST ONE DEVICE].

☞[▸▸]

3. When the PowerMax10-G2 display reads [TEST ONE DEVICE], press the [i OK] button.



The first device type is displayed, "CONTACT SENSORS".

4. Press the ▶▶ or ↩ button repeatedly to select between "CONTACT SENSORS", "MOTION SENSORS", "SMOKE SENSORS", "KEYFOBS", "SIRENS" or "REPEATERS", for example, "MOTION SENSORS".



5. After making your selection, press the OK button.

The PowerMax10-G2 display will read the device name alternating with the location.



6. Press the OK button. The PowerMax10-G2 display will read [TESTING Zxx 001] or [ACTIVATE NOW Uxx] for keyfobs.



After testing the PowerMax10-G2 display will then automatically change to read the average level for the last 24 hours (for stationary devices) or the number of activations that the control panel has received (for keyfobs).

The signal strength indications are as follows: "STRONG"; GOOD"; "POOR"; "BAD"; "BAD COM" (poor communication is detected between the device and the control panel); "NO COM." (no communication); "NOT TST" (results are shown without any performed test); "NOT NET" (device is pre-enrolled – not networked); "NONE" (keyfob 24Hr result); or "EARLY" (result of the last 24Hrs without statistics).

Pressing the ⌂ or 🔒 buttons at any stage in the procedure will take you to "<OK> TO EXIT".

5.1.3 Displaying Signal Strength Indication of All Devices

1. Repeat steps 1 to 6 from section 5.1.1 Testing all Devices.

2. When the PowerMax10-G2 display reads [TEST ALL DEVICES], press the ▶▶ and ↩ buttons repeatedly until the PowerMax10-G2 display will read [SHOW ALL DEVICES].

3. When the PowerMax10-G2 display reads [SHOW ALL DEVICES], press the OK button.



The PowerMax10-G2 display switches between the average signal strength indication for the last 24 hours and between the current signal strength indications of the first device type.*

4. Press the ▶▶ button to view the signal strength indications for the next device type.*

The signal strength indications are as follows: "STRONG"; GOOD"; "POOR"; "BAD"; "BAD COM" (poor communication is detected between the device and the control panel); "NO COM." (no communication); "NOT TST" (results are shown without any performed test); "NOT NET" (device is pre-enrolled – not networked); "NONE" (keyfob 24Hr result); or "EARLY" (result of the last 24Hrs without statistics).

* *Pressing the OK button will display the number and type of device to which the signal strength indications refer.*

Pressing the ⌂ or 🔒 buttons at any stage in the procedure will take you to "<OK> TO EXIT".

5.1.4 Displaying Signal Strength Indication of RF Devices

1. Repeat steps 1 to 6 from section 5.1.1 Testing all Devices.

2. When the PowerMax10-G2 display reads [TEST ALL DEVICES], press the ▶▶ or ↩ button repeatedly until the PowerMax10-G2 display will read

[SHOW RF PROBLEMS].

3. When the PowerMax10-G2 display reads [SHOW RF PROBLEMS], press the (i OK) button.

The PowerMax10-G2 display switches between the average signal strength indications for the last 24 hours and between the current signal strength indications of the first RF device type.*

4. Press the (▸▸) button to view the signal strength indications for the next RF device type.*

The signal strength indications are as follows: "STRONG"; GOOD"; POOR, BAD; "BAD COM" (poor communication is detected between the device and the control panel); "NO COM." (no communication); "NOT TST" (results are shown without any performed test); "NOT NET" (device is pre-enrolled – not networked); "NONE" (keyfob 24Hr result); or "EARLY" (result of the last 24Hrs without statistics).

** Pressing the (i OK) button will display the number and type of device to which the signal strength indications refer.*

Pressing the (⌂) or (🔒) buttons at any stage in the procedure will take you to "<OK> TO EXIT".



5.1.5 GPRS Communication Test

The GPRS Communication diagnostic procedure tests GSM/GPRS communication and reports the diagnostic result. In case of communication failure, detailed information of the failure is reported.

1. Make sure the system is disarmed and then press the (▸▸) button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press (i OK).

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.
The PowerMax10-G2 display will read [NEW INSTL CODE].

4. When the PowerMax10-G2 display reads [NEW INSTL CODE] press the (▸▸) or (↩) button repeatedly until the PowerMax10-G2 display will read [DIAGNOSTICS].

5. When the PowerMax10-G2 display reads [DIAGNOSTICS], press the (i OK) button.

The PowerMax10-G2 display will read [WL DEVICES].*

6. When the PowerMax10-G2 display reads [WL DEVICES], press the (▸▸) button.

The PowerMax10-G2 display will read [GSM/GPRS].

7. When the PowerMax10-G2 display reads [GSM/GPRS], press the (i OK) button.**

8. The PowerMax10-G2 display will read [PLEASE WAIT...] and will then automatically change to read [UNIT IS OK].

See the table below for a complete list of possible GSM/GPRS messages.

** If there are no wireless devices enrolled in the PowerMax10-G2 system, the PowerMax10-G2 display reads [NO DEVICES].*

*** When the (i OK) button is pressed the test result takes between 15 sec. to 4 min. before it is displayed, depending on the severity of the failure.*

Pressing the (⌂) or (🔒) buttons at any stage in the procedure will take



you to "<OK> TO EXIT" or pressing the [▸▸] button at the end of the procedure will take you to the "LAN" menu.

The following GSM/ GPRS messages are reported:

Message	Description
Unit is OK	GSM / GPRS is functioning correctly.
GSM comm. loss	The GSM/GPRS module does not communicate with the Panel
Pin code fail	Missing or wrong PIN code. (Only if SIM card PIN code is enabled.)
GSM net. fail	Unit failed with registration to local GSM network.
SIM card fail	SIM not installed or SIM card failure.
GSM not detected	GSM auto enroll failed to detect GSM/GPRS module.
No GPRS service	The SIM card does not have the GPRS service enabled.
GPRS conn. fail	Local GPRS network is not available or, wrong setting to GPRS APN, user and/or password.
Srvr unavailable	IPMP Receiver cannot be reached – Check the Server IP
IP not defined	Server IP #1 and #2 are not configured.
APN not defined	APN is not configured.
SIM card locked	After entering a wrong PIN code 3 consecutive times the SIM is locked. To unlock it enter a PUK number. The PUK number cannot be entered by the PowerMax10-G2.
Denied by server	The IPMP denies the connection request. Check that the Panel is registered to the IPMP Receiver.

5.1.6 LAN Connection Test

The LAN Connection diagnostic procedure tests Broadband Module communication to the IPMP and reports the diagnostic result. In case of communication failure, detailed information of the failure is reported.
If the Broadband Module is not registered to the PowerMax10-G2, the menu "LAN CONNECT.TEST" will not be displayed.

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [i OK].

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.
The PowerMax10-G2 display will read [NEW INSTL CODE].

4. When the PowerMax10-G2 display reads [NEW INSTL CODE] press the [▸▸] or [◂] button repeatedly until the PowerMax10-G2 display will read [DIAGNOSTICS].

5. When the PowerMax10-G2 display reads [DIAGNOSTICS], press the [i OK] button.

The PowerMax10-G2 display will read [WL DEVICES].*

6. When the PowerMax10-G2 display reads [WL DEVICES], press the [▸▸] or [◂] button repeatedly until the PowerMax10-G2 display will read [LAN].

7. When the PowerMax10-G2 display reads [LAN], press the [i OK] button.**

8. The PowerMax10-G2 display will read [PLEASE WAIT...] and will then automatically change to read [UNIT IS OK].



See the table below for a complete list of possible LAN messages.

* *If there are no wireless devices enrolled in the PowerMax10-G2 system, the PowerMax10-G2 display reads [NO DEVICES].*

** *When the [i OK] button is pressed the test result takes between 15 sec. to 4 min. before it is displayed, depending on the severity of the failure.*

Pressing the [⌂] or [🔒] buttons at any stage in the procedure will take you to "<OK> TO EXIT" or pressing the [▸▸] button at the end of the procedure will take you to the "LAN RESET OPTION" menu.

The following LAN messages are reported:

Message	Description
Unit is ok	Broadband Module is functioning correctly.
Test aborted	The diagnostic test is aborted, as follows: • AC failure – Broadband Module is set to OFF mode. • Broadband Module has not completed the power-up procedure. In this case, the installer should wait a maximum of 30 seconds before re-testing.
Comm. loss	The RS-232 serial interface between the Broadband Module and the PowerMax10-G2 failed.
Rcvr Ip missing	Receivers IP 1 and 2 settings are missing in the PowerMax10-G2.
Cable unplugged	The Ethernet cable is not connected to the Broadband Module.
Check lan config	This message appears in any of the following cases: • Incorrect Broadband Module IP has been entered. • Incorrect subnet mask has been entered. • Incorrect default gateway has been entered. • DHCP server failure.
Rcvr#1 UnReach. **Rcvr#2 UnReach.**	Receiver 1 or 2 is inaccessible, as follows: • Wrong receiver IP has been entered. • Receiver failure. • WAN Network failure.
Rcvr#1 UnReg. **Rcvr#2 UnReg.**	The PowerMax10-G2 unit is not registered to IP receiver 1 or 2.
Broadband Module timeout err.	Broadband Module does not respond to test result within 70 sec.
Invalid result	Broadband Module responds with a result code that is not recognized by the PowerMax10-G2.

5.1.7 LAN Reset Option

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.
The PowerMax10-G2 display will read [NEW INSTL CODE].

4. When the PowerMax10-G2 display reads [NEW INSTL CODE] press the ▸▸ or ◂ button repeatedly until the PowerMax10-G2 display will read [DIAGNOSTICS].

5. When the PowerMax10-G2 display reads [DIAGNOSTICS], press the OK button.

The PowerMax10-G2 display will read [WL DEVICES].*

6. When the PowerMax10-G2 display reads [WL DEVICES], press the ▸▸ or ◂ button repeatedly until the PowerMax10-G2 display will read [LAN RESET OPTION].

7. When the PowerMax10-G2 display reads [LAN RESET OPTION], press the OK button.

8. The PowerMax10-G2 display will read [REBOOT].



To reset the broadband module

9. Press the OK button.

The PowerMax10-G2 display will revert to [REBOOT].

To reset all LAN setting definitions (does not reset Monitoring Station IP definitions)

10. Press the [▸▸] button.

The PowerMax10-G2 display will read [FACTORY DEFIN.].

11. Press the [i OK] button.

The PowerMax10-G2 display reverts to [FACTORY DEFIN.].

* *If there are no wireless devices enrolled in the PowerMax10-G2 system, the PowerMax10-G2 display reads [NO DEVICES].*

Pressing the [⌂] or [🔒] buttons at any stage in the procedure will take you to "<OK> TO EXIT" or pressing the [▸▸] button at the end of the procedure will take you to the "WL DEVICES" menu.

6 CALLING UPLOAD/DOWNLOAD SERVER

Note:

This option is only used during the installation of panels monitored by compatible Monitoring Stations.

This option allows the installer to initiate a call to the upload/download server. The server uploads the PowerMax10-G2 configuration to its data base and can unload predefined parameters to the PowerMax10-G2.

To Perform Server Upload/Download

1. Make sure the system is disarmed and then press the [▸▸] button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press [i OK].

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

☞CODE

The PowerMax10-G2 display will read [NEW INSTL CODE].

4. When the PowerMax10-G2 display reads [NEW INSTL CODE] press the [▸▸] or [↰] button repeatedly until the PowerMax10-G2 display will read [START UL/DL].

5. When the PowerMax10-G2 display reads [START UL/DL], press the [i OK] button.

If the UL/DL server telephone number was already defined (see section 4.6.3.2 "Configuring the Event Types to be Reported"), the PowerMax10-G2 display will read [COMMUNICATING] which is displayed during the dialing process.

If the UL/DL server telephone number was not defined (see section 4.6.3.2 "Configuring the Event Types to be Reported"), the PowerMax10-G2 display will read [TEL# NOT DEFINED] which is displayed for approx. 30 sec. and is followed by a sad (failure) tune.

If communication has been established between the PowerMax10-G2 control panel and the upload/download server, the PowerMax10-G2 display will read [DOWNLOADING] which is displayed during the dialing process.

If communication has failed between the PowerMax10-G2 control panel and the upload/download server, the PowerMax10-G2 display will read [DIAL ATTEMPT FAIL] which is displayed for approx. 30 sec. and is followed by a sad (failure) tune.

After the downloaded/uploaded process has been completed successfully, the PowerMax10-G2 display will read [DOWNLOAD OK] which is displayed for approx. 30 sec. and is followed by a happy (success) tune.

If communication has been established between the PowerMax10-G2 control panel and the upload/download server but the downloaded/uploaded process has failed, the PowerMax10-G2 display will read [DOWNLOAD FAILED] which is displayed for approx. 30 sec. and is followed by a sad (failure) tune.

Pressing the [⌂] or [🔒] buttons at any stage in the procedure will take you to "<OK> TO EXIT".

7. MAINTENANCE

7.1 Handling System Troubles

Fault	What it means	Solution
1-WAY	The control panel cannot configure or control the device. Battery consumption increases.	i) Make sure the device is physically present. ii) Check the display for device faults, for example, low battery. iii) Use RF diagnostics to check the current signal strength and during the last 24 hours. iv) Open the device cover and replace the battery or press the tamper switch. v) Install the device in a different location. vi) Replace the device.
NOT NETWORKED	A device was not installed or not installed correctly, or, cannot establish communication with the control panel after installation.	i) Make sure the device is physically present. ii) Use RF diagnostics to check the current signal strength and during the last 24 hours. iii) Open the device cover and replace the battery or press the tamper switch. iv) Enroll the device again.
MISSING	A device or detector has not reported for some time to the control panel.	i) Make sure the device is physically present. ii) Check the display for device faults, for example, low battery. iii) Use RF diagnostics to check the current signal strength and during the last 24 hours. iv) Replace the battery. v) Replace the device.
JAMMING	A radio-frequency signal which is blocking communication channel of sensors and control panel is detected.	Locate the source of interference by switching off any wireless devices (cordless telephones, wireless ear plugs, etc.) in the house for 2 minutes then check if trouble continues. Use also RF diagnostics to check signal strength.
LOW BATTERY	The battery in a sensor, keyfob or wireless commander is near the end of its useful life.	i) For AC powered devices, check AC power is available and connected to the device. ii) Replace the device battery.
CLEAN ME	The fire detector must be cleaned	Use a vacuum cleaner to clean the detector air vents occasionally to keep them free of dust.
GAS TROUBLE	Gas detector failure	Gas detector: Disconnect and then put back the AC power supply connector CO Gas detector: Replace the detector
SIREN AC FAILURE	There is no power to the siren	Make sure that the AC power supply is connected properly
AC FAILURE	There is no power to gas sensor	Make sure that the AC power supply is connected properly
GSM NET FAIL	The GSM communicator is not able to connect to the cellular network.	i) Move the Panel and GSM unit to another location. ii) Enter and exit the installer menu iii) Disconnect GSM unit and install it again iv) Replace SIM card v) Replace the GSM unit
RSSI LOW	The GSM communicator has detected that GSM network signal is weak	Move the Panel and GSM unit to another location.
AC SUPPLY FAILURE	There is no power and the system is working on backup battery power	Make sure that the AC power supply is connected properly

Fault	What it means	Solution
COMM. FAILURE	A message could not be sent to the monitoring station or to a private telephone (or a message was sent but was not acknowledged)	i) Check telephone cable connection ii) Check that correct telephone number has been dialed. iii) Dial Monitoring Station to check whether or not events are received.
CPU LOW BATTERY	The backup battery within the control panel is weak and must be replaced (see Chapter 7 - Replacing Backup Battery).	i) Check for AC power is available in the Panel. ii) If trouble exists for more than 72 hours, replace the battery pack
CPU TAMPER	The control panel was physically tampered with or its cover was opened, or it was removed from wall.	The control panel is not closed properly. Open the control panel and then close it.
FUSE TROUBLE	The PGM fuse is burnt out or overloaded.	Make sure that the connection load conforms to that specified in the Specifications.
LINE FAILURE	There is a problem with the telephone line	i) Lift the telephone receiver and make sure a telephone line can be heard ii) Check the telephone connection to the control panel

7.2 Dismounting the Control Panel

A. Remove the screw that fastens the front unit to the back unit (see Figure 3.3).
B. Remove the 4 screws that fasten the back unit to the mounting surface (see Figure 3.3) and remove the control panel.

7.3 Replacing the Backup Battery

Replacement and first-time insertion of battery pack is similar (see Figure 3.1).

With fresh battery pack, correct insertion and tightened battery compartment lid, the TROUBLE indicator should extinguish. However, the “MEMORY” message will now blink in the display (caused by the “tamper” alarm you triggered when opening the battery compartment lid). Clear it by arming the system and immediately disarming.

7.4 Fuse Replacement

The PowerMax10-G2 has an internal fuse that has automatic reset. Therefore, there is no need to replace the fuse.

When over current condition occurs, the fuse cuts off the circuit current. Upon fault current being removed for several seconds, the fuse is automatically reset and allows current flow through the circuit again.

7.5 Replacing/Relocating Detectors

Whenever maintenance work involves replacement or re-location of detectors, always perform **a full diagnostic test according to section 5.**

Remember! A "poor" signal is not acceptable, as stated at the end of the introduction to the test procedure.

7.6 Restore Factory Defaults

If you want to reset the PowerMax10-G2 parameters to the factory default parameters, you should enter the installer menu and perform the "FACTORY DEFLT" function, as detailed below. To get the relevant parameters defaults, contact the PowerMax10-G2 dealer.

Note: *For PowerMax10-G2 with 2 installer codes, INSTALLER code and MASTER INSTALLER code, only the master installer code enables to perform factory default function.*

To Reset PowerMax10-G2 Parameters to the Factory Default Parameters

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press i OK.

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.
The PowerMax10-G2 display will read [NEW INSTL CODE].

4. When the PowerMax10-G2 display reads [NEW INSTL CODE] press the ▸▸ or ◂ button repeatedly until the PowerMax10-G2 display will read [FACTORY DEFLT].



5. When the PowerMax10-G2 display reads [FACTORY DEFLT], press the OK button.

The PowerMax10-G2 display will read [<OK> to restore].

6. Press the OK button.

The screen will now prompt you to enter your installer code again.

7. Enter your Installer Code.

The PowerMax10-G2 display will momentarily read [PLEASE WAIT ...].



The factory defaults are now retrieved.

Pressing the Home or Lock buttons at any stage in the procedure will take you to "<OK> TO EXIT".

7.7 Viewing Serial Number

The menu "SERIAL NUMBER" allows reading the system serial number and panel ID for support purposes only.
Panel ID is a unique number of the control panel that is used for registering the PowerMax10-G2 to IPMP when using GPRS.

To View the Serial Number

1. Make sure the system is disarmed and then press the ▸▸ button repeatedly until the PowerMax10-G2 display reads "INSTALLER MODE".

2. When the PowerMax10-G2 display reads [INSTALLER MODE], press OK.

The screen will now prompt you to enter your installer code.

3. Enter your Installer Code.

The PowerMax10-G2 display will read [NEW INSTL CODE].

4. When the PowerMax10-G2 display reads [NEW INSTL CODE] press the ▸▸ or ◂ button repeatedly until the PowerMax10-G2 display will read [SERIAL NUMBER].

5. When the PowerMax10-G2 display reads [SERIAL NUMBER], press the OK button.

6. The PowerMax10-G2 display will read the serial number.

7. Press the ▸▸ button.

The display will read the version of the PowerMax10-G2 unit



Pressing the Home or Lock buttons at any stage in the procedure will take you to "<OK> TO EXIT".

8 READING THE EVENT LOG

Events are stored in the event log. You can access this log and review the events, one by one. If the event log fills up completely, the oldest event is deleted upon registration of each new event.

The date and time of occurrence are memorized for each event.

When reading the event log, events are shown in chronological order - from the newest to the oldest. Access to the event log is provided by pressing the * button and not through the installer's menu. The reading and erasing process of the event log is shown below.

8.1 Reading the Event Log

1. While the system is in the normal operating mode, press the * key.

The PowerMax10-G2 display will change to [CODE _ _ _ _].

2. When the PowerMax10-G2 display reads [CODE _ _ _ _], enter the current installer code.

   The PowerMax10-G2 display reads [LIST OF EVENTS].

3. Press the [i OK] button. The latest event is shown.

   The event is displayed in two parts, for example, "Z13 alarm" then "09/02/10 3:37 P".

   The two displays will be shown alternately until pressing [i OK] again to move to the next event or until the event log times out (4 minutes).

4. Press the [i OK] button as many times as necessary to read all the required data.

8.2 Erasing and Exiting the Event Log

1. From anywhere within the event log, press the [▸▸] button.
   Note: *This is applicable only if the installer code entered.*

2. The display will change to [CLEAR EVENT LOG].

3. Press the [i OK] button.

   The display will change to [<OFF> to delete].

4. Press the [🔓] button.

   The display will change to [<OK> TO EXIT].

   At this stage in the procedure, pressing the [⌂] or [🔒] buttons will take you to "<OK> TO EXIT" without erasing the event log. Pressing the [▸▸] button will return you to "CLEAR EVENT LOG".

5. Press the [i OK] button.

   The system erases the event log and reverts to the normal operating mode. Pressing the [⌂] or [🔒] buttons at any stage in the procedure will take you to "<OK> TO EXIT".

APPENDIX A. Detector Deployment & Transmitter Assignments

A1. Detector Deployment Plan

Zone No.	Zone Type	Sensor Location or Transmitter Assignment (in non-alarm or emergency zones)	Chime (Yes / No)
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			

Zone No.	Zone Type	Sensor Location or Transmitter Assignment (in non-alarm or emergency zones)	Chime (Yes / No)
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29 (*)			
30 (*)			

Zone Types: *1 = Interior follower ✹ 2 = Perimeter ✹ 3 = Perimeter follower ✹ 4 = Delay 1 ✹ 5 = Delay 2 ✹ 6 = 24 h silent ✹ 7 = 24 h audible ✹ 8 = Fire ✹ 9 = Non-alarm ✹ 10 = Emergency ✹ 11 = Gas ✹ 12 = Flood ✹ 13 = Interior ✹ 14 = Temperature ✹ 15 = Home / delay.*

Zone Locations: *Note down the intended location for each detector. When programming, you may select one of 26 available locations (plus 5 custom locations that you can add – see Zones Devices menu).*

* Zones 29 only is hardwired zones.

A2. Keyfob Transmitter List

Transmitter Data			AUX button Assignments
No.	**Type**	**Holder**	**Skip exit delay or Arming "instant"**
1			Indicate the desired function (if any)
2			
3			
4			
5			
6			**Skip exit delay** ☐
7			**Arming "instant"** ☐
8			

A3. Emergency Transmitter List

Tx #	Transmitter Type	Enrolled to Zone	Name of holder
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			

A4. Non-Alarm Transmitter List

Tx #	Transmitter Type	Enrolled to Zone	Name of holder	Assignment
1				
2				
3				
4				
5				
6				
7				
8				

Tx #	Transmitter Type	Enrolled to Zone	Name of holder	Assignment
9				
10				

APPENDIX B. Event Codes

B1. Contact ID Event Codes

Code	Definition
101	Emergency
110	Fire
120	Panic
121	Duress
122	Silent
123	Audible
131	Perimeter
132	Interior
134	Entry/Exit
137	Tamper/CP
139	Burglary verified
151	Gas alarm
154	Flood alarm
180	Gas trouble
301	AC loss
302	Low system battery
311	Battery disconnect
313	Engineer reset
321	Bell
344	RF receiver jam detect
350	Communication trouble

Code	Definition
351	Telco fault
373	Fire detector trouble
381	Loss of supervision RF
383	Sensor tamper
384	RF low battery
393	Fire detector clean me
401	O/C by user
403	Auto arm
406	Cancel
408	Quick arm
426	Door open event
441	Armed home
454	Fail to close
455	Fail to arm
456	Partial arm
459	Recent close event
570	Bypass
602	Periodic test report
607	Walk test mode
641	Senior watch trouble

B2. SIA Event Codes

Code	Definition
AR	AC Restore
AT	AC Trouble
BA	Burglary Alarm
BB	Burglary Bypass
BC	Burglary Cancel
BR	Burglary Restore
BT	Burglary Trouble / Jamming
BV	Burglary Verified
BZ	Missing Supervision
CF	Forced Closing
CI	Fail to Close
CL	Closing Report
CP	Auto Arm
CR	Recent Close
EA	Door Open
FA	Fire Alarm
FT	Fire Detector Clean
FJ	Fire detector trouble
FR	Fire Restore
GA	Gas alarm
GR	Gas alarm restore
GT	Gas trouble

Code	Definition
GJ	Gas trouble restore
HA	Holdup Alarm (duress)
LR	Phone Line Restore
LT	Phone Line Trouble
OP	Opening Report
OT	Fail to Arm
PA	Panic Alarm
QA	Emergency Alarm
RN	Engineer Reset
RP	Automatic Test
RX	Manual Test
RY	Exit from Manual Test
TA	Tamper Alarm
TR	Tamper Restore
WA	Flood alarm
WR	Flood alarm restore
XR	Sensor Battery Restore
XT	Sensor Battery Trouble
YR	System Battery Restore
YT	System Battery Trouble / Disconnection
YX	Service Required

B3. 4/2 Event Codes

Note: *The report to Monitoring Station is on the following zones: First wireless siren - zone 31, second wireless siren - zone 32, GSM - zone 33, first 2-way keypad (MKP-150/MKP-151) - zone 35, second 2-way keypad (MKP-150/MKP-151) - zone 36.*

Alarms

Zone #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29
1st digit	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	5	5	5	5	5	5	5	5	5	5	5	5	5	5
2nd digit	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	1	2	3	4	5	6	7	8	9	A	B	C	D	E

Restorals

Zone #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29
1st digit	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	D	D	D	D	D	D	D	D	D	D	D	D	D	D
2nd digit	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	1	2	3	4	5	6	7	8	9	A	B	C	D	E

Supervisory trouble

Zone #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
1st digit	6	6	6	6	6	6	6	6	6	6	6	6	6	6	6	7	7	7	7	7	7	7	7	7	7	7	7	7
2nd digit	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	1	2	3	4	5	6	7	8	9	A	B	C	D

Low Battery

Zone #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
1st digit	8	8	8	8	8	8	8	8	8	8	8	8	8	8	8	9	9	9	9	9	9	9	9	9	9	9	9	9
2nd digit	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	1	2	3	4	5	6	7	8	9	A	B	C	D

Forced Arming – 8 users

User No.	1	2	3	4	5	6	7	8
1st digit	A	A	A	A	A	A	A	A
2nd digit	1	2	3	4	5	6	7	8

Zone Bypass

Zone #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29
1st digit	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	B	B	B	B	B	B	B	B	B	B	B	B	B	B
2nd digit	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	1	2	3	4	5	6	7	8	9	A	B	C	D	E

Panic / 24 Hours - 8 users

User No.	1	2	3	4	5	6	7	8	Panic CP	*Duress*
1st digit	2	2	2	2	2	2	2	2	2	*2*
2nd digit	1	2	3	4	5	6	7	8	9	A

Arm HOME and AWAY (Closing)

User No.	1	2	3	4	5	6	7	8	Cancel alarm	Recent Close
1st digit	E	E	E	E	E	E	E	E	E	E
2nd digit	1	2	3	4	5	6	7	8	9	C

Disarm (Opening)

User No.	1	2	3	4	5	6	7	8
1st digit	F	F	F	F	F	F	F	F
2nd digit	1	2	3	4	5	6	7	8

Trouble

Event	Fuse Fail	Fuse Restore	Jamming	Jamming Restore	AC Failure	AC Restore	CPU Low Battery	CPU Low Battery Restore	CP Tamper
1st digit	2	2	2	2	1	1	1	1	1
2nd digit	C	D	E	F	1	2	3	4	6

Event	CP Tamper Restore	No Active	COMM. & LINE Restore	Enter Test	Exit Test	Auto Test
1st digit	1	1	1	1	1	1
2nd digit	7	8	A	D	E	F

B4. Understanding the Scancom Reporting Protocol Data Format

The SCANCOM data format consists of 13 decimal digits divided into 4 groups, from left to right, as shown at the right side.
Each channel is associated with a specific event as follows:

1st "C": Fire
2nd "C": Personal attack
3rd "C": Intruder
4th "C": Open/close
5th "C": Alarm cancel
6th "C": Emergency
7th "C": Second alarm
8th "C": Trouble messages



Scancom Data Format

APPENDIX C. Glossary

This list of terms is arranged in alphabetical order. Any term indicated by cursive (italic) letters within the explanatory text can be looked up separately.

Abort Period: When an alarm is initiated, the internal sounder is activated first for a limited period of time which is the abort period set by the installer. If you cause an alarm accidentally, you can disarm the system within the abort period before the real sirens start and before the alarm is reported to the *remote responders.*

Alarm: There are 2 kinds of alarm:

Loud alarm - both internal and external sirens blare out constantly and the control panel reports the event by telephone.

Silent alarm - the sirens remain silent, but the control panel reports the event by telephone.

A state of alarm is caused by:

- Motion detected by a *motion detector*
- Change of state detected by a *magnetic contact detector* - a closed window or door is opened
- Detection of smoke by a *smoke detector*
- *Tampering* with any one of the detectors
- Pressing the two emergency buttons simultaneously (panic)

Arming: Arming the alarm system is an action that prepares it to sound an alarm if a zone is "violated" by motion or by opening a door or window, as the case may be. The control panel may be armed in various modes (see *AWAY*, *HOME, INSTANT* and *LATCHKEY*).

Assigned: Refers to zones.

Associated: Refers to devices.

AWAY: This type of arming is used when the protected site is vacated entirely. All zones, *interior* and *perimeter* alike, are protected.

Chime Zones: Allow you to keep track of activity in the protected area while the alarm system is in the disarmed state. Whenever a chime zone is "opened", the buzzer beeps twice. The buzzer doesn't beep, however, upon closing the zone (return to normal). Residences can use this feature to annunciate visitors or look after children. Businesses can use it to signal when customers enter the premises or when personnel enter restricted areas.

Note: *Your installer will never designate a 24-hour zone or a fire zone as a chime zone, because both zone types actuate an alarm if disturbed while the system is in the disarmed state.*

Although one zone or more are designated as chime

zones, you can still enable or disable the chime function.

Communicators: Refers to communication channel, for example, GSM, PSTN and broadband.

Control Panel: The control panel is a cabinet that incorporates the electronic circuitry and microprocessor that control the alarm system. It collects information from various sensors, processes it and responds in various ways. It also includes the user-interface - control keys, numerical keypad, display, sounder and loudspeaker.

Default Settings: Settings that are applicable to a specific device group.

Detector: The device (apparatus) that sends an alarm, that communicates with the control panel (e.g. Tower 20 AM is a motion detector, MCT-425 is a smoke detector)

Disarming: The opposite of arming - an action that restores the control panel to the normal standby state. In this state, only *fire and 24-hour zones* will sound an alarm if violated, but a *"panic alarm*" may also be initiated.

Disturbed Zone: A zone in a state of alarm (this may be caused by an open window or door or by motion in the field of view of a motion detector). A disturbed zone is considered "not secured".

Forced Arming: When any one of the system zones is *disturbed* (open), the alarm system cannot be armed. One way to solve this problem is to find and eliminate the cause for zone disturbance (closing doors and windows). Another way to deal with this is to impose **forced arming** - automatic de-activation of zones that are still *disturbed* upon termination of the exit delay. Bypassed zones will not be protected throughout the arming period. Even if restored to normal (closed), bypassed zones will remain unprotected until the system is disarmed.

Permission to "force arm" is given or denied by the installer while programming the system.

HOME: This type of arming is used when people are present within the protected site. A classic example is night-time at home, when the family is about to retire to bed. With HOME arming, perimeter zones are protected but interior zones are not. Consequently, motion within interior zones will be ignored by the control panel, but disturbance of a perimeter zone will cause an alarm.

Instant: You can arm the system AWAY-INSTANT or HOME-INSTANT, thereby canceling the entry delay for all delay zones for the duration of one arming period.

For example, you may arm the control panel in the HOME-INSTANT mode and remain within the protected area. Only perimeter protection is active, and if you do not expect somebody to drop in while the system is armed, alarm upon entry via the main door is an advantage.

To disarm the system without causing an alarm, use your control keypad (which is normally accessible without disturbing a perimeter zone) or use a keyfob transmitter.

Latchkey: The Latchkey mode is a special arming mode in which designated "latchkey users" will trigger a "latchkey message" to be sent to a telephone or a pager when they disarm the system.

For example, if a parent wants to be sure that their child has returned from school and disarmed the system. Latchkey arming is only possible when the system is armed in the AWAY mode.

Location: Assigning a named location to a device (e.g. Garage, Front Door etc.)

Magnetic Contact Detector, Wireless: A Magnet- controlled switch and a wireless PowerG transmitter in a shared housing. The detector is mounted on doors and windows to detect changes in state (from closed to open and vice versa). Upon sensing that a door or window is open, the detector transmits its unique identification code accompanied by an "alarm" signal and various other status signals to the control panel. The control panel, if not armed at that time, will consider the alarm system as "not ready for arming" until it receives a "restored" signal from the same detector.

Motion Detector, Wireless: A passive Infrared motion sensor and a wireless PowerG transmitter in a shared housing. Upon sensing motion, the detector transmits its unique identification code, accompanied by an alarm signal and various other status signals to the control panel. After transmission, it stands by to sense further motion.

Non-Alarm Zone: Your installer can designate a zone for roles other than alarm. For instance, a motion detector installed in a dark stairway may be used to switch on lights automatically when someone crosses the dark area. Another example is a miniature wireless transmitter linked to a zone that controls a gate opening mechanism.

Quick Arming: Arming without a user code. The control panel does not request your user code when you press one of the arming buttons. Permission to use this arming method is given or denied by the installer while programming the system.

Remote Responder: A responder can be either a professional service provider to which the home or business owner subscribes (*a Monitoring Station*) or a family relation/friend who agrees to look after the protected site during absence of its occupants. The *control panel* reports events by telephone to both kinds of responders.

Restore: When a detector reverts from the state of alarm to the normal standby state, it is said to have been "restored".

A *motion detector* restores automatically after detection of movement, and becomes ready to detect again. This kind of "restore" is not reported to the remote *responders*.

A *magnetic contact detector* restores only upon closure of the protected door or window. This kind of "restore" is reported to the remote *responders*.

Sensor: The sensing element: pyroelectric sensor, photo-diode, microphone, smoke optical sensor etc.

Signal Strength: The quality link communication between the system components and the control panel.

Smoke Detector, Wireless: A regular smoke detector and a wireless PowerG transmitter in a shared housing. Upon detection of smoke, the detector transmits its unique identification code accompanied by an alarm signal and various status signals to the *control panel*. Since the smoke detector is linked to a special *fire zone*, a fire alarm is initiated.

State: AWAY, HOME, AWAY-INSTANT, HOME-INSTANT, LATCHKEY, FORCED, BYPASS.

Status: AC fail, low battery, trouble, etc

User Codes: The PowerMax10-G2 is designed to obey your commands, provided that they are preceded by a valid security access code. Unauthorized people do not know this code, so any attempt on their part to *disarm* or defeat the system is bound to fail. Some operations, however, can be carried out without a user code as they do not degrade the security level of the alarm system.

Zone: A zone is an area within the protected site under supervision of a specific detector. During programming, the installer allows the *control panel* to learn the detector's identity code and links it to the desired zone. Since the zone is distinguished by number and name, the control panel can report the zone status to the user and register in its memory all the events reported by the zone detector. Instant and delay zones are "on watch" only when the control panel is armed, and other (*24-hour*) *zones* are "on watch" regardless of whether the system is armed or not.

Zone Type: The zone type determines how the system handles alarms and other signals sent from the device.

APPENDIX D. DEFAULT AND PROGRAMMED ZONE DEFINITIONS

Zone No.	Zone Type		Location		Chime (melody Location or Off) (*)
	Default	Programmed	Default	Programmed	
1	Delay 1		Front Door		
2	Delay 1		Garage		
3	Delay 2		Garage Door		
4	Perimeter		Back Door		
5	Perimeter		Child Room		
6	Interior		Office		
7	Interior		Dining Room		
8	Perimeter		Dining Room		
9	Perimeter		Kitchen		
10	Perimeter		Living Room		
11	Interior		Living Room		
12	Interior		Bedroom		
13	Perimeter		Bedroom		
14	Perimeter		Guest Room		
15	Interior		Master Bedroom		
16	Perimeter		Master Bedroom		
17	Perimeter		Laundry Room		
18	Perimeter		Master Bathroom		
19	Perimeter		Basement		
20	24 h / audible		Fire		
21	24 h / audible		Fire		
22	Emergency		Emergency		
23	Emergency		Emergency		
24	24 h / silent		Basement		
25	24 h / silent		Office		
26	24 h / audible		Attic		
27	24 h / audible		Den		
28	non-alarm		Yard		
29	non-alarm		Hall		
30	non-alarm		Utility room		

**** Note:** All zones are CHIME OFF by default. Enter your own choice in the last column and program accordingly.*

Industry Canada Declaration

This product meets the applicable Industry Canada technical specifications/Le présent materiel est conforme aux specifications techniques appliables d'Industrie Canada.

The Ringer Equivalence Number is an indication of the maximum number of devices allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices does not exceed five/L'indice d'équivalence de la sonnerie (IES) sert à indiquer le nombre maximal de terminaux qui peuvent être raccordés à une interface téléphonique. La terminaison d'une interface peut consister en une combinaison quelconque de dispositifs, à la seule condition que la somme d'indices d'équivalence de la sonnerie de tous les dispositifs n'excède pas 5.

The Ringer Equivalence Number (REN) for this terminal equipment is 0.3B.

WARRANTY

Visonic Limited (the "Manufacturer") warrants this product only (the "Product") to the original purchaser only (the "Purchaser") against defective workmanship and materials under normal use of the Product for a period of twelve (12) months from the date of shipment by the Manufacturer.

This Warranty is absolutely conditional upon the Product having been properly installed, maintained and operated under conditions of normal use in accordance with the Manufacturers recommended installation and operation instructions. Products which have become defective for any other reason, according to the Manufacturers discretion, such as improper installation, failure to follow recommended installation and operational instructions, neglect, willful damage, misuse or vandalism, accidental damage, alteration or tampering, or repair by anyone other than the manufacturer, are not covered by this Warranty.

The Manufacturer does not represent that this Product may not be compromised and/or circumvented or that the Product will prevent any death and/or personal injury and/or damage to property resulting from burglary, robbery, fire or otherwise, or that the Product will in all cases provide adequate warning or protection. The Product, properly installed and maintained, only reduces the risk of such events without warning and it is not a guarantee or insurance that such events will not occur.

THIS WARRANTY IS EXCLUSIVE AND EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, OBLIGATIONS OR LIABILITIES, WHETHER WRITTEN, ORAL, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR OTHERWISE. IN NO CASE SHALL THE MANUFACTURER BE LIABLE TO ANYONE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS WARRANTY OR ANY OTHER WARRANTIES WHATSOEVER, AS AFORESAID.

THE MANUFACTURER SHALL IN NO EVENT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR PUNITIVE DAMAGES OR FOR LOSS, DAMAGE, OR EXPENSE, INCLUDING LOSS OF USE, PROFITS, REVENUE, OR GOODWILL, DIRECTLY OR INDIRECTLY ARISING FROM PURCHASER'S USE OR INABILITY TO USE THE PRODUCT, OR FOR LOSS OR DESTRUCTION OF OTHER PROPERTY OR FROM ANY OTHER CAUSE, EVEN IF MANUFACTURER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

THE MANUFACTURER SHALL HAVE NO LIABILITY FOR ANY DEATH, PERSONAL AND/OR BODILY INJURY AND/OR DAMAGE TO PROPERTY OR OTHER LOSS WHETHER DIRECT, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR OTHERWISE, BASED ON A CLAIM THAT THE PRODUCT FAILED TO FUNCTION.

However, if the Manufacturer is held liable, whether directly or indirectly, for any loss or damage arising under this limited warranty, **THE MANUFACTURER'S MAXIMUM LIABILITY (IF ANY) SHALL NOT IN ANY CASE EXCEED THE PURCHASE PRICE OF THE PRODUCT,** which shall be fixed as liquidated damages and not as a penalty, and shall be the complete and exclusive remedy against the Manufacturer.

When accepting the delivery of the Product, the Purchaser agrees to the said conditions of sale and warranty and he recognizes having been informed of.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so these limitations may not apply under certain circumstances.

The Manufacturer shall be under no liability whatsoever arising out of the corruption and/or malfunctioning of any telecommunication or electronic equipment or any programs.

The Manufacturers obligations under this Warranty are limited solely to repair and/or replace at the Manufacturer's discretion any Product or part thereof that may prove defective. Any repair and/or replacement shall not extend the original Warranty period. The Manufacturer shall not be responsible for dismantling and/or reinstallation costs. To exercise this Warranty the Product must be returned to the Manufacturer freight pre-paid and insured. All freight and insurance costs are the responsibility of the Purchaser and are not included in this Warranty.

This warranty shall not be modified, varied or extended, and the Manufacturer does not authorize any person to act on its behalf in the modification, variation or extension of this warranty. This warranty shall apply to the Product only. All products, accessories or attachments of others used in conjunction with the Product, including batteries, shall be covered solely by their own warranty, if any. The Manufacturer shall not be liable for any damage or loss whatsoever, whether directly, indirectly, incidentally, consequentially or otherwise, caused by the malfunction of the Product due to products, accessories, or attachments of others, including batteries, used in conjunction with the Products. This Warranty is exclusive to the original Purchaser and is not assignable.

This Warranty is in addition to and does not affect your legal rights. Any provision in this warranty which is contrary to the Law in the state or country were the Product is supplied shall not apply.

Warning: The user must follow the Manufacturer's installation and operational instructions including testing the Product and its whole system at least once a week and to take all necessary precautions for his/her safety and the protection of his/her property.

1/08

The technical documentation as required by the European Conformity Assessment procedure is kept at:
UNIT 6 MADINGLEY COURT CHIPPENHAM DRIVE KINGSTON MILTON KEYNES MK10 0BZ. Telephone number: 0870 7300800, Fax number: 0870 7300801

VISONIC LTD. (ISRAEL): P.O.B 22020 TEL-AVIV 61220 ISRAEL. PHONE: (972-3) 645-6789, FAX: (972-3) 645-6788
VISONIC INC. (U.S.A.): 65 WEST DUDLEY TOWN ROAD, BLOOMFIELD CT. 06002-1376. PHONE: (860) 243-0833, (800) 223-0020. FAX: (860) 242-8094
VISONIC LTD. (UK): UNIT 6 MADINGLEY COURT CHIPPENHAM DRIVE KINGSTON MILTON KEYNES MK10 0BZ. TEL: (0870) 7300800 FAX: (0870) 7300801
PRODUCT SUPPORT: (0870) 7300830
VISONIC GMBH (D): KIRCHFELDSTR. 118, D-42015 DÜSSELDORF, GERMANY, FAX (0211) 60069619 Email: info-dach@visonic.com
VISONIC IBERICA: ISLA DE PALMA, 32 NAVE 7, POLÍGONO INDUSTRIAL NORTE, 28700 SAN SEBASTIÁN DE LOS REYES, (MADRID), ESPAÑA. TEL (34) 91659-3120, FAX (34) 91663-8468. www.visonic-iberica.es
INTERNET: www.visonic.com

©VISONIC LTD. 2010 POWERMAX10-G2 Installer Guide D-302756 Rev 0 (08/10)

MADE IN ISRAEL

©Visonic LTD. 2010 Printed in Israel 03/2010 Designed by Inbar Graphic Design

Visonic®
For a secure way of life

www.visonic.com